

INFINITY²⁸

USER MANUAL

JULY 27, 2026




Handi Quilter®



USER MANUAL

JULY 27, 2026



© 2026 Handi Quilter, Inc. All rights reserved.

The information contained in this document is subject to change without notice. If you find any problems in the manual, please report them to us in writing. This document is not warranted to be error-free. Handi Quilter, Inc. assumes no responsibility or liability for any errors or inaccuracies that may appear in the informational content contained in this manual. Images, illustrations, and screenshots in this manual are for reference purposes only and may not exactly match your machine. Due to continuous product improvements, some features, labels, colors, or components may vary without notice. These differences do not affect the operation or use of the machine as described in this manual.

Handi Quilter, Infinity 28, Amara 24, Amara 20, Amara ST, HQ Simply Sixteen, Moxie XL, Moxie, Pro-Stitcher, Pro-Stitcher Lite, Gallery 3 Frame, Studio 3 Frame, HQ Loft Frame, HQ Little Foot Frame, Lift Frame and TruStitch are either trademarks or registered trademarks of Handi Quilter, Inc. Infinity 28 U.S. Patent No. 9,809,912; 9,394,639; 9,195,225; digital tensioner U.S. Patent No. 8,997,669, camera U.S. Patent No. 8,633,982.

Printed in the United States of America.

Part number: QM33128

How to Use This Manual

Notes, Important Notes, and Cautions

-  **NOTE:** A NOTE indicates important information that helps you make better use of your Handi Quilter product.
-  **IMPORTANT:** An IMPORTANT note provides information that is essential to properly using your Handi Quilter product.
-  **CAUTION:** A CAUTION indicates a potential for causing harm to your quilting machine, the quilt, or to yourself.
-  **ONLINE:** Indicates there is more information online, such as a video.

Finding Information

What are you looking for?

Find it here

Warranty information.....	Owner's manual
Safety information.....	Owner's manual
Regulatory information	Owner's manual
What's included with your machine.....	Owner's manual
Machine specifications	Owner's manual
Frame setup information.....	Gallery 3 Frame installation manual
Machine setup information.....	Owner's manual
How to thread your machine	Quick reference card
Needle system for your machine.....	Quick reference card
Getting started with quilting	Getting Started videos
Online videos.....	www.handiquilter.com/videocatalog/
Basic maintenance	Owner's manual
Troubleshooting	Owner's manual
Tips and tricks.....	www.handiquilter.com/webinar/ www.handiquilter.com/videocatalog/
Training and education options	www.handiquilter.com/education/overview/
Customer Care / Technical Support.....	1-877-MY-QUILT (697-8458) or 801-292-7988 Available 8:00 AM to 5:00 PM Mountain Time, Monday to Friday HQcares@handiquilter.com
Community.....	Forum: www.handiquilter.com/forum/ Blog: www.blog.handiquilter.com/ Facebook: www.facebook.com/HandiQuilter
Non-English versions of this manual (when available)	www.handiquilter.com/manuals/

Contents

- How to Use This Manual..... 2**
- Congratulations On Your Purchase..... 5**
 - What’s Included With Your Machine..... 5
- Important Safety Information 6**
- About Your Machine..... 11**
 - General Specifications 11
 - Get to Know Your Infinity 28 12
- Installation and Setup..... 15**
 - Carriage 15
 - Power Cord..... 16
 - Handlebars 16
 - Touch-Screen Display..... 18
 - Thread Tray and Thread Mast..... 19
 - Install the Infinity 28-Video Camera..... 21
 - Optional Accessory: Easy-Click Ruler Base™ 22
- Using Your Machine..... 23**
 - Power Switch 23
 - Lighting..... 23
 - Machine Needle 24
 - Hopping Feet 26
 - Glide Foot 27
 - Bobbin and Bobbin Tension..... 27
 - Easy-Touch Tension™ 29
 - Threading the Machine 32
- Quilting with the Infinity 28..... 34**
 - Preparing to Quilt..... 34
 - Free-Motion Quilting..... 36
 - Micro Quilting 36
 - Computer-Guided Quilting: Pro-Stitcher® 36
- Using the Touchscreen Display..... 38**
 - Overview of the Main Screen..... 39
 - Stitching Modes..... 42
- Toolbar Options..... 46**
 - Using the Infinity 28-View Video Camera..... 46
 - Controlling the Lights 47

Machine Tools	47
Quilting Timer, Alarm, and Stitch Counter.....	48
On-screen Calculator	50
Software Updates	50
Diagnostics	52
Machine Settings	52
Easy-Touch Tension™ Presets	53
Low-Bobbin Alarm	54
Handlebar Button Options	56
Laser Light	58
Alarms	59
Tieoffs.....	60
Set Language	61
Information Screens	61
Machine Maintenance	65
Clean and Oil Your Infinity 28	65
Maintenance Schedule.....	66
Troubleshooting	66
Appendix 1	73
Federal Communications Commissions (FCC) Declaration of Conformity (For USA Only).....	73
Canadian Department of Communications Compliance Statement (For Canada Only)	73
Radio Interference (Other than USA and Canada)	73
Appendix 2: QR Codes for Infinity 28 Videos	74
Handi Quilter Quilting Machine Limited Warranty	75
Handi Quilter Warranty Registration.....	77
Infinity 28 New Owner and Training Checklist and Certificate	78

Congratulations On Your Purchase

You haven't just purchased a quilting machine, you've joined the Handi Quilter family and we welcome you. You have acquired the most advanced quilting machine available in today's market.

Handi Quilter is committed to innovation, reliability, customer service, and education. Our machines are By Quilters, for Quilters® and we are committed to your quilting success. With that in mind, we invite you to bookmark our website: www.HandiQuilter.com and invite you to visit to learn more about the art of quilting. Your new quilting friends are already there, waiting for you! Remember, if you ever have questions, your local HQ authorized retailer can help you. If the retailer is not available, contact Handi Quilter directly at HQCares@HandiQuilter.com or by calling us at 1-877-697-8458, Monday through Friday, 8:00 AM to 5:00 PM Mountain Time.

Keep the carton and packing materials. You will need them if you need to return the machine to the dealer or send it for repair. If you don't pack the machine properly or if you don't use the correct packaging materials, the machine could be damaged. Handi Quilter is not liable for damage that occurs during return shipping.

➡ **IMPORTANT:** These packaging materials are designed to prevent the machine from being damaged. Keep them in case you need to bring this machine to the dealer or send it for repair.

What's Included With Your Machine

- Bobbins (5 pieces, one in bobbin case)
- Needle (134 MR, Round) size 16 (pack of 10)
- Needle (134 MR, Round)) size 18 (pack of 10)
- Bobbin Case
- Thread tray and thread mast
- EZ Pen Oiler
- Screwdriver
- Power Cord
- 2.5 mm hex wrench
- 3 mm hex wrench
- 4 mm hex wrench
- 5 mm hex wrench
- M8/M10 open end wrench
- Video Camera
- Open-toe Handi Foot (closed-toe foot installed)
- Handi Quilter Longarm Quilting Pins
- Handi Quilter Bobbin Winder
- User Manual on USB
- Quick Reference Card
- Infinity 28 Quilting Machine (including Pro-Stitcher® carriage, front handlebars, front display, cables)
- Handi Quilter Longarm Quilting Pins
- Glide foot

Important Safety Information

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. See the full Declaration of Conformity in the Appendix.

- ➡ **IMPORTANT:** Do not operate your Infinity 28 quilting machine until you have completely read the information contained in this manual. Please keep all packaging and order information for warranty purposes.

IMPORTANT SAFETY INSTRUCTIONS

Read all instructions before using this machine.

When using this machine, basic safety precautions should always be followed, including the following:

DANGER — To reduce the risk of electric shock:

- A quilting machine should never be left unattended when plugged in. Always unplug the machine from the electrical outlet immediately after using and before cleaning.

WARNING — To reduce the risk of burns, fire, electric shock, or injury to persons:

- Always unplug the machine from the electrical outlet before cleaning, servicing, making adjustments, changing the needle or accessories, or when the machine is left unattended, to reduce the risk of electric shock or injury.
- This product must be grounded. In the event of a malfunction or breakdown, grounding provides a path of least resistance for electric current to reduce the risk of electric shock. This product is equipped with a cord having an equipment grounding conductor and a grounding plug. The plug must be connected to an appropriate outlet that is properly installed and grounded in accordance with all local codes and ordinances.
- **DANGER:** Improper connection of the equipment grounding conductor can result in a risk of electric shock. The conductor with insulation having an outer surface that is green, with or without yellow stripes, is the equipment grounding conductor. If repair or replacement of the cord or plug is necessary, do not connect the equipment grounding conductor to a live terminal.
- Check with a qualified electrician or service technician if the grounding instructions are not completely understood, or if there is doubt as to whether the product is properly grounded.
- Do not modify the plug provided with the product. If the plug will not fit the outlet, have a proper outlet installed by a qualified electrician.
- The Infinity 28 is heavy. Never attempt to lift it alone. Always use two people when lifting. Always lift from the throat of the machine, not from the handlebars.
- Do not unplug by pulling on the cord. To unplug, grasp the plug, not the cord.
- Keep fingers away from all moving parts. Use caution around the needle and any sharp external components.
- Always use the proper needle plate. Using the incorrect needle plate may cause the needle to break and result in injury.
- Change the needle often. Do not use bent or dull needles.

- Switch the machine to the OFF (0) position before making any adjustments in the needle area, including threading the needle, changing the needle, threading the bobbin, or changing the hopping foot.
- Never drop or insert foreign objects into any opening.
- The Infinity 28 is intended for indoor use only. Do not use outdoors or in wet or damp locations.
- Do not store or operate the Infinity 28 in extreme temperatures.
- Use the Infinity 28 only for its intended purpose as described in this manual and only with accessories and attachments recommended by Handi Quilter.
- Never operate the Infinity 28 if the power cord or plug is damaged, or if the machine is not working properly. If a mechanical or electrical problem occurs, return the machine to an authorized service center or the manufacturer for examination, repair, or adjustment.
- It is not recommended to use the Infinity 28 quilting machine with any quilting frame other than those recommended by Handi Quilter.
- Never operate the machine with any air openings blocked. Keep ventilation openings free from the accumulation of lint, dust, and loose cloth.
- Do not operate the machine where aerosol (spray) products are being used or where oxygen is being administered.
- Do not pull or push the machine across the fabric excessively while stitching. Excessive force may deflect the needle and cause it to break.
- Use only needles designed for free-motion quilting and recommended by Handi Quilter for this machine. Other types of needles may break during normal quilting.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- Cleaning and user maintenance shall not be performed by children without supervision.

△ CAUTION: Class II Laser Product. This machine includes a Class II needle-positioning laser that projects a red dot onto the quilt to show where the needle will enter the fabric. Laser radiation is emitted from the needle area when the needle laser is on. Do not stare into the beam or point the laser beam toward any person or animal. Use the laser only as described in this manual.

The needle laser has a maximum output of 1.0 mW and a wavelength of 650 nm. The needle laser is not a user-serviceable component. Do not remove covers, modify the laser, or attempt to service or replace the laser. Service must be performed only by an authorized Handi Quilter retailer or qualified service technician.

△ Caution: Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

Consignes de sécurité

Cet appareil est conforme à la partie 15 de la réglementation de la FCC. Son fonctionnement est soumis aux deux conditions suivantes : (1) cet appareil ne doit pas causer d'interférences nuisibles, et (2) cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant provoquer un fonctionnement indésirable.

Veuillez noter : n'utilisez pas votre machine à quilter Infinity 28 avant d'avoir lu entièrement les informations contenues dans ce manuel. Veuillez conserver tous les emballages et les informations de commande à des fins de garantie.

CONSIGNES DE SÉCURITÉ IMPORTANTES

Lisez toutes les consignes avant d'utiliser la machine.

Lorsque vous utilisez cette machine, vous devez toujours prendre des précautions de sécurité de base, notamment ce qui suit :

DANGER — Pour réduire le risque de choc électrique :

Une machine à quilter ne doit jamais être laissée sans surveillance lorsqu'elle est branchée. Débranchez toujours la machine de la prise électrique immédiatement après usage et avant de la nettoyer.

AVERTISSEMENT — Pour réduire le risque de brûlures, d'incendie, de choc électrique ou de blessures :

- La Infinity 28 est très lourde. Ne jamais tenter de la soulever seul. Utilisez toujours deux personnes pour la soulever. Soulevez toujours la machine à partir de la gorge, non pas à partir des poignées.
- Débranchez toujours la Infinity 28 de la prise électrique lors des travaux d'entretien, du changement d'aiguille, de la suppression des blocages de fil, ou lorsqu'elle est laissée sans surveillance.
- Ne pas débrancher en tirant sur le cordon. Pour débrancher, saisir la fiche, non le cordon.
- N'approchez pas les doigts des parties mobiles. Faites preuve de prudence lorsque vous vous approchez de l'aiguille ou de composants externes tranchants.
- Changez souvent d'aiguille. N'utilisez pas d'aiguilles tordues ou émoussées. « Chaque quilt mérite une nouvelle aiguille ».
- Mettez la machine sur la position 0 ou de symbole d'arrêt pour l'éteindre lorsque vous effectuez des réglages dans la zone de l'aiguille : enfilage de l'aiguille, changement d'aiguille, bobinage de la canette, changement de pied, etc.
- Ne faites jamais tomber et n'insérez jamais d'objets étrangers dans une ouverture.
- La Infinity 28 doit être utilisée uniquement à l'intérieur dans un endroit non humide.
- La Infinity 28 ne doit pas être rangée ou utilisée à des températures extrêmes.
- Utilisez la Infinity 28 uniquement pour son usage prévu indiqué dans ce manuel.
- Pour débrancher la machine de la prise murale, mettez l'interrupteur sur arrêt, puis retirez la fiche de la prise en tirant à partir de la fiche et non du cordon. N'utilisez jamais la Infinity 28 si le cordon est endommagé ou ne fonctionne pas correctement. En cas de problème mécanique ou électrique, renvoyez la Infinity 28 au centre de service agréé le plus proche ou au fabricant pour inspection, réparation, ou réglage électrique ou mécanique.
- Il est déconseillé d'utiliser la machine à quilting Infinity 28 avec un cadre de machine à quilter autre que ceux recommandés par Handi Quilter.
- Utilisez cette machine à quilter uniquement pour l'usage prévu décrit dans ce manuel. Utilisez uniquement les accessoires recommandés par le fabricant décrits dans ce manuel.
- Ne jamais utiliser la machine si des ouvertures d'air sont bloquées. Gardez les ouvertures de ventilation de la machine exemptes d'accumulation de peluches, poussières et morceaux de tissu.
- Ne pas utiliser là où des aérosols (vaporisateurs) sont utilisés ou de l'oxygène est administré.
- Ne pas tirer ni pousser trop fort la machine sur le tissu lors de l'exécution des points. Cela pourrait provoquer une déviation de l'aiguille et entraîner la fracture.
- N'utilisez que les aiguilles conçues pour le quilting en piqué libre et recommandées par Handi Quilter pour cette machine. D'autres types d'aiguilles risqueraient de se fracturer au cours d'un quilting normal.
- Ne pas laisser les enfants jouer avec la machine. Une attention particulière est nécessaire lorsque cette machine est utilisée par ou à proximité d'enfants.

- Cette machine peut être utilisée par des enfants de 8 ans et plus, ainsi que par des personnes atteintes d'un déficit physique, sensoriel ou mental, peu expérimentées ou ayant peu de connaissances, à condition que ces personnes reçoivent les instructions de sécurité et la supervision nécessaires à l'utilisation de la machine et qu'elles comprennent les risques encourus.
- Les travaux de maintenance et de nettoyage ne peuvent pas être effectués par des enfants sans supervision.

△ MISE EN GARDE : Produit laser de classe II. Cette machine comprend un laser de positionnement d'aiguille de classe II qui projette un point rouge sur le quilt pour indiquer l'endroit où l'aiguille pénétrera dans le tissu. Un rayonnement laser est émis depuis la zone de l'aiguille lorsque le laser de l'aiguille est activé. Ne regardez pas directement le faisceau et ne dirigez pas le faisceau laser vers une personne ou un animal. Utilisez le laser uniquement comme décrit dans ce manuel.

Le laser de l'aiguille a une puissance de sortie maximale de 1,0 mW et une longueur d'onde de 650 nm. Le laser de l'aiguille n'est pas une pièce réparable par l'utilisateur. Ne retirez pas les capots, ne modifiez pas le laser et ne tentez pas de l'entretenir ou de le remplacer. L'entretien doit être effectué uniquement par un détaillant Handi Quilter autorisé ou un technicien de service qualifié.

△ Mise en garde — l'utilisation de commandes ou de réglages, ou l'exécution de procédures autres que celles spécifiées dans ce document, peut entraîner une exposition dangereuse au rayonnement.

Save these instructions.

This machine is intended for household or commercial use.

Disclaimer

Handi Quilter and its Retailers are in no way legally responsible or liable for damage to the Infinity 28 when used improperly or not in accordance with the guidelines stated in this manual or when used on machine quilting frames not recommended by Handi Quilter.

To use the machine safely

1. Carefully watch the needle when sewing. Do not touch the hand wheel, take up lever, needle, or other moving parts.
2. Turn the machine off and unplug the cord in the following cases:
 - when you have stopped using the machine
 - when you replace or remove the needle or any other part
 - when you check or clean the machine
 - when you leave the machine unattended
3. Connect the machine directly to the wall outlet or to a surge protector that connects directly to the wall outlet. Do not use extension cords.

To increase the life of your machine

1. Do not store this machine in areas exposed to direct sunlight or high humidity. Never use or store the machine near a heater, an iron, a halogen lamp or other hot things.

2. Use only neutral soaps or detergents to clean the machine. Benzene, solvents and scouring powders can damage the case and the machine and therefore should never be used.
3. Do not drop or bump the machine.
4. Always consult the manual to replace or fix the hopping foot, needle or any other part of the machine. If necessary contact an authorized Handi Quilter retailer or Handi Quilter technical support.

To repair or adjust the machine

If the machine breaks down or needs adjustment, first check the troubleshooting chart in the appendix to inspect and adjust the machine yourself.

For more product information and updates, visit our website at www.HandiQuilter.com.

The contents of this manual and product specifications are subject to change without prior notice. Check for updated manuals at www.handiquilter.com/manuals/.

Recommended Use and Storage

1. It is recommended that our products be operated within in a temperature range of 60°F to 90°F.
2. Store products in a climate-controlled environment with the following provisions:
 - Store machine in the original packaging, which contains the internal supports designed specifically to maintain and protect the machine during transport or storage
 - Detach cables and accessories before packing
 - To best protect your electronics, store them in the original packaging, especially any that arrived in anti-static containers
3. Storage or use in an environment other than what is recommended may result in
 - Damaging condensation
 - Rust
 - Premature wear
 - Overheating
 - Poor performance
 - Shortened battery life
4. The display warranty, if applicable, is VOID if the display is stored in temperatures below 32°F or above 110°F. Do not leave the display in a vehicle or other enclosed space where the temperature may exceed 110°F.
5. If the product is stored at a temperature above or below the recommended operating range, allow the machine to acclimate to the operating environment before use.

About Your Machine


General Specifications

The Infinity 28 uses high-tech electronics and an innovative touch-screen user interface to offer greater functionality and ease of operation to home quilters than ever before conceived in the quilting industry. The Infinity 28 quilting machine is a high quality machine that both incorporates robust design features and is easy to service.

Sewing Opening Dimensions	(260 mm X 711 mm) 10.25 inches X 28 inches
Sewing Speed	Manual Mode: from 25 stitches per minute to 3100 stitches per minute Regulated Mode: from 0 stitches per minute to full speed
Stitches Per Inch	5 stitches per inch to 24 stitches per inch Basting mode: one stitch per quarter inch, one stitch per half inch, one stitch per inch, one stitch every two inches, and one stitch every four inches
Needle System	134MR High speed Round shank with needle bar thread guide QM10617-1 (short) zusing QM10558 needle clamp screw (chamfered not pointed)
Needle Sizes (recommended)	From 80/12 to 130/21
Hook System	Rotary, Horizontal Axis, M-class bobbin
Bobbin Type	Aluminum, Class M
Bobbin Case	Type MF
Motor Type	Brushless DC
Needle Positioning	Up and down, walking stitch, on-screen needle position buttons
Electrical Power	
US/Canada*:	105 – 120 VAC, 47-63Hz, 600W peak
Rest of world:	100 – 250 VAC, 47-63Hz, 600W peak
	* Complies with international certifications
Sew Foot Stroke/Lift	5 mm
Needle Bar Stroke	35.3 mm
Take-Up Stroke	73 mm
Lubrication, main components	Kluber Lube, permanent
Lubrication of hook	Velocite 10, Texaco 22


Get to Know Your Infinity 28

Left side view




1. Handi Accessory Rail
2. USB for video camera
3. Video camera mounting hole
4. Handlebars
5. Display
6. Front on/off switch
7. Needle laser adjustment knob

Close-up view of needle area




8. Head frame thread guide
9. Needle bar
10. Needle clamp screw
11. Needle bar thread guide
12. Needle
13. Closed toe hopping foot
14. Needle plate with thread cutter
15. Foot release lever
16. Presser bar

Right side view



- 17. Take-up lever
- 18. Three-hole thread guide
- 19. Thread break sensor
- 20. Thread guide
- 21. Thread mast and thread tray
- 22. Spool pins
- 23. Hand wheel
- 24. Handi Accessory Rails
- 25. Tension assembly with take-up spring
- 26. Stirrup thread guide
- 27. Tension thread guide

Back Panel



28. Carriage encoder connection (for Stitch Regulation)

29. Pro-Stitcher connection

30. Main On/Off power switch

31. Power cord connection

Installation and Setup

Carriage

You should have already set up the Gallery3 Frame. Refer (or scan the QR code) to the BILT app for detailed instructions about setting up the frame.



 **NOTE:** For further details regarding carriage installation, please refer to the Pro-Stitcher Infinity 28 Installation Manual.

 **IMPORTANT:** Make sure the Gallery3 Frame is set up for a 28-inch machine, not a 26/24-inch machine.

To install the carriage and machine on the frame

1. Place the carriage on the table rails, ensuring that the stitch regulator faces the back of the frame.
2. Place the machine on the carriage.


 **CAUTION:** The Infinity 28 is heavy. Never attempt to lift it alone. Always use two people when lifting. Always lift from the throat of the machine, not from the handlebars or needle bar.

3. Plug the mini plug cable into the back of the machine and the stitch regulation encoder on the carriage.

 **NOTE:** The cable has several contacts and must be plugged in all the way in order to make proper contact, or it will not function properly.

 **NOTE:** To connect the Pro-Stitcher Data Cable, ensure the molded line on the black plastic connector is oriented upward. This line should be positioned at the 12 o'clock mark, with flat surfaces visible at the 3 o'clock and 9 o'clock positions. Insert the cable into the machine connector, then twist the metal threaded portion of the cable clockwise to engage the threads. Tighten the connection securely, and gently pull on the cable to confirm it is properly seated. If the cable is not correctly connected, the display will not communicate with the Pro-Stitcher motors.

 **IMPORTANT:** If you ever need to remove the machine from the carriage, disconnect the stitch regulation mini cable from the stitch regulator. Failure to unplug the cable when removing the machine from the carriage could result in damage to the machine, cable, encoder, or carriage.



Power Cord

To install the power cord

- Insert the cord into the power connector on the rear of the machine. Plug the three-prong end into power source. Do not turn on the machine until the handlebars and display are installed.

To disconnect the power cord

- Pull the two red tabs on the end of the cord away from the machine. While holding the tabs, gently remove the power cord from the connector.

For more information, see Power Switch in the Using Your Machine section of this manual.

-  **NOTE:** Make sure that the machine is off before plugging into power source. The rear power switch should be in the 0, or off, position.



Handlebars

The Infinity 28 has handlebars at the front of the machine.


-  **CAUTION:** To prevent any electrical damage to the handlebars, always turn off all power to the machine when connecting or disconnecting the handlebars.

To install the front handlebars

1. Locate the three hex screws for the front handlebars (two M5 x 18 and one M6 x 25 hex screw), two 5mm washers, a 6mm washer, and both the 4mm and 5mm hex wrenches.




2. Place the 5mm washers on the M5 hex screws and place into the top two holes in the handlebar bracket.




 **NOTE:** You may find it is easier to remove the front poles from the Gallery 3 Frame so you can position yourself behind the machine's head.

3. Align the bracket and hex screws with the pre-drilled holes behind the machine's head and fully tighten the top two screws with the 4mm hex wrench.



4. Place the 6mm washer on the M6 hex screw and insert it into the bottom hole and fully tighten with the 5mm hex wrench.
5. Plug the small 1/8" plug front handle bar cable into the connector above the manual tension adjustment knob, circled.



To adjust the hand-position angle of the front handlebars

Each side of the handlebar has two adjustment levers which allow them to be independently adjusted to a comfortable position.

ONLINE: For more information about adjusting the handlebars of the Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Loosen the levers by turning them counterclockwise. Then grasp the front of the handlebars and adjust them inward or outward, or up or down to a comfortable position for general quilting. Tighten the levers by turning them clockwise when you are happy with the position.

To use the handlebars for micro quilting

When micro quilting, you'll want to have your hands (and therefore, handlebars) close to the quilt top. In addition to adjusting the angle of the front handlebars, you can adjust how closely positioned the handlebars are relative to the quilt.


Configurable Handlebar Buttons

The Infinity 28 handlebars are configurable so you can decide which functions you want the left and right handlebar buttons to do when pressed.

The machine comes from Handi Quilter configured to have the right handlebar control starting and stopping quilting, and increasing stitching speed in Manual mode or stitches per inch in Regulated mode. The left handlebar controls cycling the needle up and down, and slowing the stitching speed or decreasing stitches per inch. You can switch the functions from one side to the other when you set up your machine.

 **NOTE:** It is important to note that you will not be able to switch the handlebar buttons to match the switched configuration.

You can also select from several functions and assign one to the star button and another to the diamond button. For example, choose to have the diamond button perform a tie-off and the star button perform another desired function.



 **NOTE:** Pressing the plus or minus buttons on the handlebars also increases or decreases tension after you press the **Easy-Touch Tension™** button on the Main screen. As long as the Easy-Touch Tension button is enabled, pressing the plus or minus buttons controls the tension setting.

For more information about configuring the handlebars and buttons, see To customize the handlebar buttons in the Toolbar Options section of this manual.


 **NOTE:** The traditional handlebar configuration has the Start and Pause buttons on the right handlebar and the Needle Up and Down buttons on the left handlebar.

Touch-Screen Display



The Infinity 28 comes with a 12" display that integrates with the Pro-Stitcher.

To install the front display

1. Attach the Pro-Stitcher bracket to the display by aligning the four captive screws in the bracket with the holes in the back of the display.
2. Tighten the screws firmly with the 3mm hex tool being careful not to over tighten them.



3. Locate four M4x10 hex screws and the 3mm hex wrench (found in the Pro-Stitcher Box). Place the M4 screws through the display bracket hinge and into the metal bracket at the front of the machine.
4. For better alignment, loosely tighten all four screws at first and then fully tighten them.
5. There is one USB C cable for power and communications for the display. It is connected at machine front bracket at the top left side. Plug the USB C cable into the USB C connection on the left side of the display.



Thread Tray and Thread Mast

To install the thread tray on the machine

 **ONLINE:** Scan the QR code to access the BILT app for step-by-step setup instructions.



1. Locate the T-nut and the knob for the thread tray. If necessary, thread the T-nut onto the end of the knob a couple turns.
2. Align the T-nut with the opening at the front of the Handi Accessory Rail on the bottom of the machine's throat, insert into the track, and slide a few inches into the track.



3. Slide the slot of the spool tray onto the knob's bolt. Finger tighten the knob until the spool tray is firm against the throat of the machine.



To adjust the position of the thread tray

After the thread tray and thread mast are installed, you will be able to slide the tray and thread mast along the length of the machine.

- Loosen the knob at the bottom of the thread tray until the tray can move freely along the Handi Accessory Rail. Position the tray where you want it and finger tighten the knob.




Install the Infinity 28-Video Camera

A video camera comes with the Infinity 28 machine to preview the quilting on the back.

To install the Infinity 28-View video camera

1. Place the bracket onto the machine, lining up the screw inserts. Make sure the camera is oriented away from the machine and facing up. This will ensure that the camera will show the bottom of the quilt.
2. Insert the camera bracket bolt through the bracket and into the machine inserts. Fasten the bolt clockwise with a 5 mm hex wrench.
3. Plug in the USB connector to the USB port on the base end cap.
4. Tuck the cable into the accessory track to the left side of the camera.
5. Take the T-slot clip and, while inserting the cable inside the accessory track, snap the clip over the track to cover the cable and hold it in place.

For more information about the using the video camera and viewing the video images on the display, see *Using the Video Camera* in the *Toolbar Options* section of this manual.



Optional Accessory: Easy-Click Ruler Base™

If you plan to use rulers and templates with the Infinity 28, you will need to purchase the ruler base to give you a large, stable surface on which to rest the ruler or template. The ruler base and rulers and templates are optional accessories. For more information, visit www.handiquilter.com/shop/.

To install the ruler base

🖱️ **ONLINE:** For more information about installing the ruler base, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



1. Center the ruler base over the base end cap of the machine. The spring-loaded ball bearing is aligned with the needle.
2. Slide the metal hooks of the ruler base into the slots at the back of the base end cap and snap the ruler base into place.



To remove the ruler base

- Grasp the front corners of the ruler base and lift up to unsnap from the base end cap. Slide the ruler base forward and lift off of the machine.

To use rulers and templates with your quilting machine

⚠️ **CAUTION:** Use only one-quarter inch thick rulers with your machine. Do not use rotary-cutting rulers as they are too thin and can easily slip under the hopping foot. Always use a ruler base or extended table to stabilize the ruler.

Keep the ruler flat and quilt only where ruler is held securely. Avoid losing control by stopping and repositioning your hand and the ruler.

Apply gentle three-point pressure to the ruler, as follows:

1. Press the ruler against any side of the hopping foot.
2. Press machine against ruler.
3. Press ruler against ruler base with only as much force as is necessary to keep the ruler from slipping. Too much pressure will keep the machine from moving.

The quilting line is approximately a quarter inch away from the ruler edge for most machines. The markings on all Handi Quilter rulers take this into consideration.

✍️ **NOTE:** Set the machine to stop in the needle-down position to keep the machine from moving while making adjustments with the ruler.

Using Your Machine

Power Switch



 **ONLINE:** For more information about powering on the Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

There are two power switches for your machine. The main power switch is at the rear of the machine and another power switch is at the front of the machine for added convenience.

The machine is turned on when both switches are turned on. The machine is turned off when both switches are off. However, you may turn off the machine functions by turning off only the front switch if you will be returning to quilting within a day.

Turn on the back switch first by toggling the switch from the 0 position to the 1 position. Then turn on the front switch by pressing it. The front switch will not turn on the machine unless the back switch is already on.

 **NOTE:** If pressing the Infinity 28 front power switch does not turn off the machine, press and hold the switch for at least 5 seconds to force a shutdown.

 **IMPORTANT:** If you will not be using the machine for more than a day, we recommend you turn off both switches and unplug the power cord from the power source.

 **IMPORTANT:** Refer to the safety instructions.

Lighting



 **ONLINE:** For more information about adjusting lighting on your Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

The Infinity 28 includes lights to make it easy for you to see your quilting area: a light under the throat of the machine and a light ring that illuminates the needle and stitching area.

Turning the lights on and off is done through the touch-screen display. For more information about turning on the machine lights, see *To Control the Lights on the Machine* in the *Toolbar Options* section of this manual.

Machine Needle

Use only the recommended needle system for your Infinity 28 quilting machine. The machine was timed to use these specific types of needles and is designed to work with the high quilting speeds and multi-directional stitching the Infinity 28 offers.

The Infinity 28 uses the MR needle system.

 **NOTE:** The needle has a round shank rather than a shank with a flat side like home sewing machines use.

If you use the recommended needle, you will experience:

- Fewer skipped stitches
- Less needle breakage
- Less thread breakage, especially at high speeds
- Less thread splicing or shredding
- Optimum fabric protection



 **IMPORTANT:** Change the needle regularly. We recommend you use a new needle for each new quilt loaded on the machine, and any time the needle becomes bent, dull, or burred.


 **CAUTION:** A damaged needle may result in poor stitching quality or may even damage the machine or your quilt.

To change the needle

 **ONLINE:** For more information about changing the needle, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.




1. Move the needle bar to the up position by pressing the needle up/down control on the handles.
2. Turn off all power to the machine.
3. Loosen the needle bar clamp screw with the 2.5mm hex wrench.
4. Remove the old needle by pulling it down. Discard the old needle in a safe way.





5. With the scarf of the needle (indentation at the back of the needle) facing the rear of the machine and the long groove down the front of the needle facing the front of the machine, push the needle all the way up into the needle bar until it stops. Check the sight opening to verify that the top of the needle can go no farther up.

Side view: Example of 134 MR Needle



6. Carefully tighten the needle bar clamp screw with a 2.5mm hex tool.

△ **CAUTION:** Check the needle to confirm it is fully inserted. The needle bar has a sight opening above the needle bar clamp screw. Make sure the needle is touching the top of the sight opening. If it isn't, the machine timing will be off and it may be possible for the needle to collide with internal parts causing damage not covered by warranty.



△ **CAUTION:** Although you can use your fingers to tighten the needle bar clamp screw, we recommend that after finger-tightening the screw you use the 2.5mm hex wrench to tighten it just a bit more. The Infinity 28 runs at very high speeds and this ensures the needle will not loosen while quilting. However, do not over tighten the needle clamp screw as this may strip the threads of the screw. Stripped threads are not covered under the warranty. It may also become difficult to insert the needle properly into the needle bar. Once the screw no longer turns freely by hand, gently turn the screwdriver until the screw is tightened snugly.

Needle size	Thread size
14	monofilament, 100 wt. silk, 60 wt. poly, mylar
16	monofilament, hologram, 100 wt., 80 wt., 60 wt., 50 wt., 40 wt. silk, poly or cotton thread
18	40 wt. cottons and poly, 30 wt. cottons and poly
20	Any thread 30 wt. and heavier such as 12 wt., 19 wt., 30 wt.

Machine Quilting Tip: Needle Requirements

For general quilting, a size 16/100 needle will accommodate most threads and fabrics. Heavier threads, such as top stitch and some decorative threads, require a larger needle such as 18/110 or 21/130. Lofty batts and heavier fabrics such as denim, canvas, or densely woven fabric may also require a larger needle.

Hopping Feet


 **ONLINE:** For more information about changing a foot on your Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



Your machine comes with two hopping feet: a closed-toe foot (comes installed) and an open-toe foot. Use the closed-toe foot for everyday quilting, and use the open-toe foot when you need greater stitch visibility (such as when you are micro quilting).

To change the Hopping Foot

1. Raise the needle and the foot to their highest position. To remove the foot, pull the lever down with your finger to release the foot, pull down on the foot and remove it.
2. To install a foot, with the lever pulled down, slide the foot up onto the mount and pull the lever up to tighten the foot up onto the mount. The opening on the foot lines up with a pin on the front of the adaptor. The adaptor lever locks onto a pin at the rear of the foot.



 **NOTE:** For more information on our line up of Handi Feet, check out our optional accessories at www.handiquilter.com/product-category/machine-accessories/.

Glide Foot


The Glide Foot is a bowl-shaped foot that easily glides around appliqué, embellishments, or other dimensional elements on a quilt.

The wide bowl shape provides easy access to the needle for threading. Multi-directional cross-hair markings on the foot help to accurately guide quilting.

Your machine should already be fitted with the foot mount that works with the interchangeable feet. These instructions describe how to attach the Glide Foot.

To change the Glide Foot

1. If another foot is on the mount, pull the lever down with your finger to release the foot, pull down on the foot and remove it.
2. Slide the Glide Foot up onto the mount and pull the lever up to tighten the foot up onto the mount. The opening on the foot lines up with a pin which the lever locks onto.



Bobbin and Bobbin Tension

The Infinity 28 quilting machine uses M-class bobbins that are larger than sewing machine L-class bobbins. The larger bobbins enable you to quilt for a longer time between bobbin changes.

The Infinity 28 also has a low-bobbin alarm. For more information about the low-bobbin alarm, see To configure the low-bobbin alarm settings in the Toolbar Options section of this manual.

To wind the bobbin

The Infinity 28 comes with a separate bobbin winder. For full instructions about using the bobbin winder, see the instruction manual that was packaged with the bobbin winder.

 **ONLINE:** For more information about using the bobbin winder, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



To insert the bobbin into the bobbin case



📺 **ONLINE:** For more information about inserting the bobbin into the bobbin case, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

⚠ **CAUTION:** To prevent personal injury always turn off the front power switch while inserting and/or removing bobbin case or anytime your hands are near the needle area, such as when you change the needle.

1. Place the bobbin in the bobbin case so that the thread pulls off clockwise when viewing the open side.
2. Slide the thread through the slot and under the tension spring, leaving approximately five to six inches of thread hanging loose.



To test bobbin tension

The bobbin tension is the foundation tension for the entire machine. Always set the bobbin tension first.

🔧 **NOTE:** Check the bobbin tension each time a new bobbin is inserted.

📺 **ONLINE:** For more information about testing and adjusting the bobbin tension, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



1. With the bobbin properly in the bobbin case, hold the bobbin case in the palm of your hand with the open end facing up.
2. Wrap the thread two to three around the index finger of the opposite hand and lift the bobbin up. The bobbin case should lift up on its side, and slightly lift out of your hand. If the bobbin will not lift up on its side, the bobbin tension is too loose and if it lifts out of your hand, the bobbin tension is too tight.

To adjust the bobbin tension

- Make the adjustment using the screw in the center of the tension spring. Turn clockwise to tighten and counterclockwise to loosen the bobbin case tension. Make tiny adjustments to the bobbin tension and test again.




To insert the bobbin case into the machine

 **ONLINE:** For more information about inserting the bobbin case into the machine, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



1. Move the needle to the up position. Turn off the front power to the machine.
2. Place the bobbin in the bobbin case so that the thread pulls off clockwise when viewing the open side.
3. Slide the thread through the slot and under the tension spring, leaving 5 to 6 inches of thread hanging loose.
4. To fit the bobbin case onto the hook spindle in the machine, orient the bobbin case as shown in the photo with alignment notch to the right. Push the bobbin case inward until it clicks into place.



Alignment notch

 **NOTE:** Do not insert the bobbin case into the machine by lifting the lever on bobbin case. Use the lever only for removing the bobbin case.

Easy-Touch Tension™

One of the joys of quilting with the Infinity 28 is its ability to handle many different types of thread. You can quilt with almost any high-quality thread as long as you first adjust the bobbin tension and then adjust the top tension to suit the thread you've chosen.

Puckering, gathers, and thread breakage occur when the top tension is too tight. Loops and thread nests occur when the top thread tension is too loose. Tension may need to be adjusted depending on the fabric, thread, or batting you are using on the project.

 **NOTE:** Top tension should be adjusted after the bobbin case foundation tension adjustment is made.

 **NOTE:** Dark threads will be thicker (because of dye) than light threads of the same weight. The type or brand of thread may also affect tension settings. Each time you change threads, you should check your tension.

 **ONLINE:** For more information about adjusting the top-thread tension, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



 **IMPORTANT:** Before adjusting your top tension remember to pull the top thread up into the tension discs (flossing the thread) or it will float outside the discs providing little or no top tension. This could cause significant tension or thread nesting problems on the bottom side of the quilt.

The Infinity 28 can also save a top tension setting for up to three types of thread. For more information about setting the top tension presets, see To customize the top tension presets in the Machine Settings section of this manual.


Machine Quilting Tip: Test the tension settings before quilting

The best way to make sure the top and bottom tension settings are balanced is by quilting. We keep 4-inch squares of light solid fabric on hand to place at the side of the quilt on the extra batting and backing. Then quilt some loops and swirls and look at the stitches on top and underneath to ensure the tension looks good. Fine tune the tension as needed.

 **NOTE:** The video camera mounted below the quilt is a great way to see the stitching on the back of the quilt and verify that you have good tension settings.

To adjust the top tension

1. Test stitching with a scrap of fabric placed on the extra batting and backing at the side of the quilt.




The number on the tension button displays the current tension setting. It changes as you increase or decrease tension.

Press to increase top-thread tension.

Press to decrease top-thread tension.

The screenshot shows the INFINITY28 control panel. At the top, there's a play/pause button, the brand name 'INFINITY28', and icons for camera, light, tools, settings, and info. Below this, there are buttons for 'M' (Machine) and 'R' (Reverse), a gauge icon, and a large tension button showing '3100' with minus and plus icons. To the right, there are three preset buttons labeled 1, 2, and 3 with values 80, 100, and 120 respectively, each with a plus or minus icon. At the bottom, there are several function buttons: a knot icon with '4', a circular arrow icon with '57', a gear icon with '8.8', and a triangle icon. Arrows point from the text labels to the tension button and the preset buttons.

2. Adjust the tension by pressing the plus (+) and minus (–) buttons on the Main screen. The tension value appears on the Electronic Tension Button on the Main screen. This value changes as you press the plus (+) and minus (–) buttons.



3. Continue to test the stitching on the fabric scrap until you are happy with the tension. If you want to save that setting as one of the tension presets, see To customize the top tension presets in the Machine Settings section of this manual.

 **NOTE:** On the left front cover of the machine there is a black manual tension knob, should you prefer to set your tensions this way. The display will change when the knob is used, just like it does when the display screen is used. The knob has small electronic clicks/detents to give you tactile feedback. When facing the knob, turn it clockwise to tighten and counterclockwise to loosen the top tension.

Tension Quick Start Guide

Bobbin adjustments are minute, like ticks of the clock.

1. **Always adjust bobbin thread tension first.**

2. Stitch out to check top tension.

3. If top thread looks like Diagram A



Problem: The top thread is too tight.

Solution: Press the Easy-Touch Tension button on the Main screen and loosen the top thread tension by pressing the minus button.

4. If top thread looks like Diagram B

Problem: The top thread is too loose.

Solution: Touch the Easy-Touch Tension button on the Main screen and tighten the top thread tension by pressing the plus button.




Threading the Machine




ONLINE: For more information about threading your Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

Handi Quilter recommends that you select and use only high-quality threads for your quilts.

To thread the machine





1. Place thread cone onto spool post ① on the thread tray, insert the thread through the thread-mast eyelet ② from back to front, continuing to the thread guide ③.
 2. Continue to the three-hole thread guide ④. Wrap all three holes from back to front, being careful not to cross threads. This is recommended for most threads. However, some very delicate threads or metallic threads may require less tension. If you are having problems with thread breaking, try threading only one or two holes of three-hole thread guide.
 3. The thread continues down to the tension assembly ⑤.
- ➡ **IMPORTANT:** The thread must be flossed up between the two tension discs. If the thread is not firmly in place between the two tension discs, the thread will lay on top of the tension discs (no tension) and thread looping on the bottom of the quilt can occur.
4. After the thread is in place, be sure that the thread catches on the take-up spring ⑥ . Then guide the thread under the tension thread guide ⑦ and under the stirrup thread guide ⑧ .
 5. Bring the thread up and through the hole of the take-up lever ⑨ from back to front, and then through the pigtail thread guide ⑩, through the needle bar thread guide hole ⑪, from back to front, and then through the pigtail thread guide ⑫.
 6. Make sure the thread follows the groove down the front of the needle and insert the thread through the eye of the needle from front to back ⑬. While pulling thread through the eye of the needle be careful that the thread does not twist around the needle.

Quilting with the Infinity 28

Preparing to Quilt

1. Make sure your machine has been cleaned, oiled, has a new needle, and that the tracks on the frame are free from threads or other debris. If the machine isn't already plugged in, plug it in now.
2. Select your thread and wind one or more bobbins.
3. Turn on the main power switch at the back of the machine and then use the front power button on the front of the machine to turn the machine on or off as needed.
4. Set your bobbin tension and thread your machine.
5. After loading your quilt, use a scrap of fabric along the edge of the quilt backing and batting to test your top tension. Make adjustments to the top tension as needed.

To load the quilt

 **ONLINE:** To see how to load the quilt onto the frame, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.




To bring bobbin thread to the top of the quilt

 **ONLINE:** To see how to bring the bobbin thread to the top of the quilt, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



1. After the machine is threaded, locate needle up/needle down button on the handlebar. Move the machine over the quilt to your starting location.
2. While firmly holding the tail of the needle thread, press the needle up/down button twice, causing the needle to go down through the quilt sandwich and then back to the up position.
3. Move the machine two to three inches while holding the needle thread in place. The bobbin thread will pull up through to the top of the quilt.
4. Grasp the bobbin thread loop and pull it to the desired length. Reposition the needle to the starting location, tie off the threads by quilting a few stitches in place (or press the Tieoff button on the Main screen), and begin quilting.



 **NOTE:** If you have customized either the star or diamond button to do a tieoff, press that button on the handlebar instead. For more information about configuring the handlebar buttons, see *To Customize the Handlebar Buttons* in the *Machine Settings* section of this manual.

To start or stop quilting

 **ONLINE:** For more information about getting started with your stitching, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Start or stop the machine at any time by pressing the Start/Pause button on the handlebars.



To tie off threads when starting and ending quilting

 **ONLINE:** To see how to perform a thread tie off when starting and ending quilting, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Touch the **Tieoff** button on the Main screen to perform a tieoff. For more information about tying off your stitching, see To configure automatic tieoffs in the Toolbar Options section of this manual.



 **NOTE:** If you have customized either the star or diamond button to do a tieoff, press that button on the handlebar instead. For more information about configuring the handlebar buttons, see *To Customize the Handlebar Buttons* in the *Machine Settings* section of this manual.

To use the bobbin-thread cutter

The Infinity 28 will cut the bobbin thread for you following a tieoff. It cuts the bobbin thread at the needle plate, leaving sufficient bobbin thread for the next time you bring the bobbin thread to the top of the quilt for quilting. You will need to trim the needle thread following a tieoff.

 **ONLINE:** To see how to perform a bobbin-thread cut, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Tie off your quilt stitches and press the bobbin-thread cutter button on the Main screen. If the needle is in the down position, it is raised to the up position before the thread is cut. You'll hear a slight beep to let you know the thread has been cut.
-  **NOTE:** If you configured either the star or diamond button on the handlebars to do a bobbin-thread cut, you can also press that button on the handlebars. For more information about configuring the handlebar buttons, see *To Customize the Handlebar Buttons* in the *Toolbar Options* section of this manual.
-  **NOTE:** If you want a bobbin thread tail that is longer than one inch, move the machine away from your tieoff stitches before pressing the bobbin-thread cut button. The thread tail will match the distance you moved the machine from the tieoff stitches.
-  **NOTE:** You will still need to trim the bobbin thread tails when you remove the quilt from the frame. The length of the thread tail is determined by how far you move your machine between tying off the stitching and doing the bobbin thread cut.

Free-Motion Quilting



 **ONLINE:** For examples of different types of free-motion quilting, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

Machine Quilting Tip: Relax!

When quilting, relax your hands and maintain a light touch on the handlebars. Gripping the handlebars too tightly may cause body tension resulting in poor quilting quality. The Infinity 28, in combination with the Gallery 3 Frame system, will give you a smooth even glide while quilting.

Micro Quilting

For more information about adjusting the front handlebars for micro quilting, see *To Use the Handlebars for Micro Quilting* in the *Installation and Setup* section of this manual.



 **ONLINE:** For more information about micro quilting, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

Computer-Guided Quilting: Pro-Stitcher®

The Pro-Stitcher quilting system integrates Handi Quilter's quilting machines, including the Infinity 28, with the best computer technology for computer-guided quilting using digital designs. The software is managed from a state-of-the-art display that is conveniently mounted on top of the machine. This rich and full-featured software is easy to learn and makes precise quilting simple and fun.

Using the Pro-Stitcher Display on Your Infinity 28

When you use Pro-Stitcher with your Infinity 28, the display works for both the machine and Pro-Stitcher. The Infinity 28 software functions normally on the display; however, when also using Pro-Stitcher, the Pro-Stitcher software sometimes overrides some of the Infinity 28 settings. For more information about how Pro-Stitcher works with the Infinity 28, see the Pro-Stitcher user manual.

First turn on the Infinity 28; then turn on the Pro-Stitcher display. Both Pro-Stitcher software and the Infinity 28 application console start up.

 **NOTE:** After the Infinity 28 application console starts, it works the same as if you were running it from the touch-screen display, as described in the *Using the Touch-Screen Displays* and *Toolbar Options* sections of the manual.

While the Infinity 28 and Pro-Stitcher are running, a menu appears in the upper left corner of the screen. Touch a button on this menu to switch between using Pro-Stitcher, using the Infinity 28 console, and using Pro-Stitcher Designer. You can also open the onscreen keyboard, switch to the video camera, or close the menu from view.

Pro-Stitcher Designer. You can also open the onscreen keyboard, switch to the video camera, or close the menu from view.



Use Pro-Stitcher to quilt, or switch to free-motion quilting by disengaging the Pro-Stitcher motors. (In Pro-Stitcher, select **Pro-Stitcher** tab , then the **Gears** button.)

Handlebar Star and Diamond Buttons with Pro-Stitcher

Four functions in Pro-Stitcher override your custom settings for the star and diamond buttons on the handlebars: when creating 2-point (star button) and multi-point areas (diamond button), when starting and stopping freehand recording (star button). and when marking lines for quilting (diamond button). See the Infinity 28 version of the Pro-Stitcher manual for more information about how the star and diamond buttons work with these functions.

Updating the Infinity 28 Software

If you are running the Infinity 28 from a Pro-Stitcher display, the Update screen has only the machine icon. You will update the Infinity 28 machine software using the Update option on the Tools menu. However, the Infinity 28 application console software is part of the Infinity 28 version of the Pro-Stitcher software. Make sure you are also using the latest version of the Pro-Stitcher software.

Using the Touchscreen Display

The Infinity 28 display works for both the Infinity 28 machine console and the Pro-Stitcher. You can use the display to alternate between stitch-regulated and non-stitch regulated operation, to control settings for how you prefer your machine to operate, and to use tools such as counting stitches on a quilt or logging how much time it took to finish your quilt.

 **NOTE:** The Infinity 28 comes with the 12" Pro-Stitcher display. You will use the Pro-Stitcher display to control the functions of the Infinity 28 and the Pro-Stitcher.

Buttons are selected, or on, when they are dark purple and display white insets or graphics. Buttons are off when they are grey and display white or lighter gray text or graphics. When you touch a button, it will toggle on or off, open a pop-up box for you to enter information, or open a screen with more options.



Button Selected / On



Button Not Selected / Off


If a button cannot be used, usually because another process is underway, it will be gray.



Button Not Available

Overview of the Main Screen

The Infinity 28 Main screen provides quick access to all functions.



Touch this icon for the view from the video camera mounted on the side of the machine. For more information about the camera options, see *Using the Video Camera* in the *Toolbar* section of this manual. For information about installing the video camera, see *To Install the Video Camera* in the *Installation and Setup* section of this manual.



Touch this icon to open the Lights screen. For more information about turning lights on and off, see *Controlling the Lights* in the *Toolbar Options* section of this manual.



Touch this icon to open the Tools. For more information about the various tools, see *Machine Tools* in the *Toolbar Options* section of this manual.




Touch this icon to open the Settings. For more information about the various settings, see *Machine Settings* in the *Toolbar Options* section of this manual.



Touch this icon to see system information, as well as a machine threading guide and needle/thread guide. For more information about the system information that is available, see *Information Screens* in the *Toolbar Options* section of this manual.

This area of the Main screen controls the stitching modes. It is currently set to manual mode and shows the current stitches per minute setting and three stitches-per-minute presets. This area changes according to the stitching mode you've selected.




These buttons remain the same regardless of the stitching mode you choose.



Tie-off button: Use this button to perform a tieoff at the start or finish of your stitching. Touch the button and gently move the machine to perform the micro stitches. The number below the image indicates how many micro stitches will be performed.

For more information about how to configure the number of micro stitches in a tieoff, see *To configure tieoffs* in the *Toolbar Options* section of this manual.



Bobbin-thread cutter button: Touch this button to perform a bobbin thread cut. The Infinity 28 cuts the thread at the needle opening in the needle plate, leaving enough bobbin thread for your next pullup.

📺 **ONLINE:** For information about using the Bobbin-thread cut button, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.




Easy-Touch Tension™ button: Touch this button and then use the plus (+) and minus (–) buttons on the screen or on the handlebars to increase or decrease the upper tension. The number on the button indicates the current tension setting.

For more information about electronic tension, see *Top Thread Tension* in the *Machine Settings* section of this manual.

📺 **ONLINE:** For information about setting the top-thread tension, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.





Reset-bobbin button: Press this button after a bobbin change if you are using the low-bobbin alarm. This resets the low-bobbin reading to indicate you are using a full bobbin. The number on this button shows an estimate of how much thread remains on the bobbin. This number updates as you quilt. As the number gets closer to zero, the bobbin is running out of thread. For more information about the low-bobbin settings, see To add a new bobbin configuration and record bobbin capacity in the Toolbar Options section of this manual.

⚠ **IMPORTANT:** Touch this button only to reset the bobbin capacity to indicate a full bobbin. If you want to open the Low Bobbin Alarm screen, select the **Machine Settings** toolbar button and then select the **Low Bobbin Alarm** screen.



Tension Release: This button toggles between released tension mode and normal mode. Press the button to release tension discs, press it again to return to the last saved tension setting.


⚠ **Caution:** If you fail to hit the button to return to normal tension, you will have tension issues.



Needle-stop button: Touch the button to alternate between having the needle stop in the up or down position when you stop stitching. Your choice displays in dark purple (as shown at the left).

This button does not move the needle, but rather indicates your preference for the final needle position when quilting is stopped.

Other Needle Buttons



Needle Buttons

Left needle button: Press for top position, needle at highest position.

Center needle button: Press for middle position, take-up lever up, completion of stitch.

Right needle button: Press for down, needle at lowest position.

Needle Reverse Motion Buttons

Left Arrow: Needle Reverse

Right Arrow: Needle Forward

✍ NOTE Hold either button to walk the needle

⚠ **Caution:** Only use the reverse arrow to move the needle slightly in the reverse direction.

Stitching Modes

The Infinity 28 enables you to choose between two modes of stitch regulation (Cruise or Precision) or to choose manual stitching. It also includes a basting mode.

Manual Stitching Mode

When using the manual stitching mode, the length of the stitch is determined by how quickly or slowly you move the machine around the quilt, in combination with the number of stitches per minute (up to 3100) you have selected. For a consistent stitch length, you will need to move the machine at a consistent speed. Experiment with different combinations of quilting speed and stitches per minute to find what optimally works for you.

To use manual stitching mode


 **ONLINE:** For information about using manual stitching mode, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Touch the **Manual** button and then specify the stitches per minute (SPM) by pressing the plus (+) or minus (–) buttons on the screen or selecting one of the stitches-per-minute presets. Pressing the plus (+) or minus (–) buttons on the screen to change the stitches per minute has the same effect as pressing the plus (+) or minus (–) buttons on the handlebars.

To configure the manual stitching mode preset speeds

The manual mode preset speeds are three stitches-per-minute speeds, up to 3100 stitches per minute (SPM), that are saved for quick access from the Main screen. After you set the speeds, you can choose one of the presets when in Manual stitching mode and it becomes the current speed. Perhaps you want one speed when doing overall quilting, a different speed for ruler work, and yet another speed for micro quilting.



1. Select Manual stitching mode by touching the **Manual** button.
2. Press the plus (+) button to increase or the minus (–) button to decrease the current stitches per minute setting.
3. Touch the save button next to one of the stitches per minute presets to save the current setting as a preset.

Machine Quilting Tip: Getting started with Manual mode

Set the machine at a medium speed (such as 1000) and begin moving it until you become accustomed to the resistance. By moving the machine faster, the stitches will begin to elongate. The stitch speed can either be increased or the machine can be moved slower to get the stitches at your desired length. By moving the machine slower, the stitches get shorter and can build up on top of each other, break the thread, or make it extremely difficult to unpick. The stitching speed can be decreased, while maintaining a constant motion with the machine to bring the stitches to the desired length.

Stitch Regulation


There are two stitch regulation modes: Cruise and Precision.

To use Cruise stitch regulation

📺 **ONLINE:** For information about using Cruise stitch regulation, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Touch the **Regulated** button and then touch the **Cruise** button.



After you press the Start/Pause button on the handlebars, the machine immediately begins quilting according to the stitches-per-minute and stitches-per-inch settings. The Start stitching indicator in the upper-left corner of the screen turns green and the needle begins moving up and down. Similarly, as you bring your quilting to a stop, the needle will continue stitching at the cruise speed (stitches per minute) until you press the stop button on the handlebars. The minimum speed of the needle is dependent upon the stitches-per-minute setting you choose. Handi Quilter recommends beginning with a setting of 200. Begin moving the machine to avoid stitching in place for too long.

Machine Quilting Tip: When to use Cruise stitch regulation


The constant minimum stitching speed featured in the Cruise stitch regulation is useful for precise placement of stitching, such as when backtracking along the tops of feathers or when creating sharp points such as the point of a star or the bottom of a heart.

To use Precision stitch regulation



 **ONLINE:** For information about using Precision stitch regulation, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.

- Touch the **Regulated** button and then press the **Precision** button.



After you press the Start/Pause button on the handle bars, you must begin moving the machine for it to begin quilting according to the stitches-per-unit of measure setting. The Start stitching indicator in the upper-left corner of the screen turns green but the needle doesn't automatically begin moving up and down. When you begin moving the machine, stitching begins. When you stop moving the machine, stitching stops but just until you move it again.

 **NOTE:** When using Precision stitch regulation, if you stop moving the machine but do not press the Stop/Pause button, after two minutes it will time out and a message box appears to let you know you will need to press the Start/Pause button to resume quilting.

 **CAUTION:** Always make sure the power is off when changing the needle, replacing the bobbin, or placing your hands near the needle to avoid unwanted stitching in your quilt or in your fingers.

Machine Quilting Tip: When to use Precision stitch regulation

Precision stitch regulation mode is useful for ruler work. Stitch along the length of the ruler for the span of your hand and stop moving the machine, but do not press the Stop button. When you stop moving the machine, the needle pauses. Move the ruler and then begin moving the machine to continue quilting. Precision stitch regulation helps you to avoid bobbles and uneven stitches.

Machine Quilting Tip: Getting started with stitch regulation

Set the machine to your desired stitch length. Begin moving the machine to become accustomed to the resistance. The machine motor will slow down or speed up to maintain a consistent stitch length according to how quickly or slowly you move the machine. Moving the machine too fast or in radical or jerky movements will defeat the stitch regulator function.

Machine Quilting Tip: Quilting speed while in stitch-regulation mode

It is unlikely that you will move the Infinity 28 across the quilt too fast. However, if you do, it will result in an overspeed condition if the machine can't maintain stitch regulation. An overspeed alarm, if turned on, will alert you that you should slow down your quilting to maintain stitch regulation.


Basting Mode

The Infinity 28 includes five basting stitch options for basting a quilt. The basting stitch options are available in stitch regulation mode only.

The stitches-per-inch setting ranges between 5 stitches per inch and 24 stitches per inch. If you continue to press the minus (–) button on the screen, after 5 you will see B1/4", B1/2", B1", B2", and B4".

B1/4"	One stitch every quarter inch of movement of the machine
B1/2"	One stitch every half inch of movement of the machine
B1"	One stitch every one inch of movement of the machine
B2"	One stitch every two inches of movement of the machine
B4"	One stitch every four inches of movement of the machine

🔗 **ONLINE:** For information about basting mode, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



To baste a quilt


1. Touch the **Regulated** button.
2. Press the minus (–) button next to the stitches-per-inch box on the screen until you see 5 stitches per inch. Continue touching the minus (–) button and the four basting stitch options appear. Choose the one you want to use – either B1/4", B1/2", B1", B2", or B4".
3. Begin basting the quilt by pressing the Start button. As you move the machine across the quilt, it will perform a stitch (needle down and then needle up) every one quarter, one half, one, two, or four inches according to your choice of basting stitch length.

Machine Quilting Tip: Basting the edges of the quilt

If you are basting the edges of the quilt to the batting and backing, choose a low number of stitches per inch, somewhere between 5 to 8 stitches per inch, rather than one of the basting-mode stitches. This will help to prevent the hopping foot from going between the batting and quilt top.

Toolbar Options

The toolbar is in the upper-right corner of the console at all times.



Using the Infinity 28-View Video Camera


 **ONLINE:** For information about using the camera on the Infinity 28, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



When you touch the video icon, you will have the option to turn off all of the machine lights by touching the light bulb icon at the right of the screen. This often results in clearer images from the video camera under the quilt. When you quit using the video camera, the lights return to their previous setting.

As you move the machine across the quilt, the view of the quilt from the video camera appears on the touch-screen display.


The camera has auto focus, so there is no need to adjust the lens. It may take a moment for the camera to focus when first opening the camera view. Turning off the lights, adjusting brightness, contrast and/or zoom level may improve the visibility of the stitches.



Toggles light on/off. Usually turning the lights off gives a more clear picture of the stitches.



Zoom in or out. Pressing the icon resets to default.



Increase or decrease the contrast. Pressing the icon resets to default.



Increase or decrease the Brightness. Pressing the icon resets to default.




Exit the camera view and return to the console window.

Controlling the Lights

Your Infinity 28 comes equipped with two standard lights.

To control the lights on the machine

- To open the Lights screen, touch the **Lights** icon in the toolbar. After selecting the icon, it turns dark purple and Lights screen opens.




all lights button / on

When lights are on, the on/off button displays in color. Touch the on/off button to quickly turn off the light.



all lights button / off

Touch the small top “All Lights” button to turn on all of the lights at once. If they are already on, touch the button to turn off all lights at once.



Otherwise, use the slider to vary the intensity of the light. Touch the black dot and drag up to increase the intensity or down to decrease the intensity. The intensity settings are saved when lights are turned off and will be the same when you turn them on again.

Machine Tools

To open the machine tools, touch the Tools icon in the toolbar. After selecting it, the icon turns dark.



The **Tools** button is selected (dark).

Choose from the four tools at the bottom of the screen.

Sets the quilting timer, the quilting alarm, and the stitch counter.


Opens the on-screen calculator.

Updates the machine's software.

Opens the Diagnostics screen.



After you select an option, the button background turns dark and the screen changes for you to do any customization of that setting. The next time you touch the Tools icon, the last Tools option you used appears.



Quilting Timer, Alarm, and Stitch Counter

The timers screen enables you to track the amount of time you work on a quilt, to set a timer to remind you when your quilting time is up, and to track the number of stitches on a quilt.


 **ONLINE:** For more information about the quilting timer, quilting alarm, and stitch counter, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Touch the **Tools** icon in the toolbar. Then touch the **Timers** button. Press the **Home** button to return to the Main screen.

To track how much time you spend on a quilt

Use the quilting timer to keep track of how much time you spend on a quilt. The quilting timer measures time the machine is actually quilting, not the time the machine is on but idle.



1. When you begin a new quilt, press **Reset**.
2. When you are ready to begin tracking the time spent on a quilt, press **Play**. Proceed with your quilting. When you are through quilting for a time, press **Pause**.
3. When you resume quilting, press **Play** again. The quilting timer will continue tracking your time and add it to the previously recorded time.

To track the number of stitches in a quilt


Use the stitch counter to count the number of stitches in a quilt.

- Press the **Reset** button to zero-out the counter when you begin a new quilt. To see the lifetime stitch counter for your machine, see the Information screen.



To set the quilting alarm

Use the quilting alarm to set a reminder that alerts you when the time you've allotted for quilting is done. After you enable the alarm, the time begins to count down. Unlike the quilting timer, this alarm measures elapsed time, not machine quilting time. The example below shows only 3 minutes and 55 seconds are remaining before the alarm will sound.



1. Specify the amount of time that will elapse before the alarm will go off. Fine tune the alarm setting by pressing the plus (+) or minus (-) buttons which changes the alarm setting by one minute at a time.
2. Touch the alarm icon to turn on the quilting alarm. When the time has elapsed, an alarm will sound.

On-screen Calculator

The Infinity 28 includes a basic on-screen calculator. It functions like all basic calculators. For example, press a number button and a function button followed by another number button. Function buttons include addition (+), subtraction (−), multiplication (x) and division (÷). After you've pressed the numbers and the function buttons, press the equal sign (=) for the answer.

- Touch the **Tools** button in the toolbar. Then touch the **Calculator** button along the bottom of the screen. Press the **Home** button to return to the Main screen.



← The **Tools** button is selected, or dark.

Software Updates

From time to time Handi Quilter releases software updates for their machines. This update feature enables you to take advantage of the latest new capabilities added to machines. When an update is released, download the updated file(s) to a USB drive using a computer that is connected to the Internet.

- Touch the **Tools** button in the toolbar. Then touch the **Update** button along the bottom of the screen. Press the **Home** button to return to the Main screen.



- After downloading the updated software to a USB drive, insert the drive in the designated USB port in the left side of the machine display. Look for the message in the bottom bar that confirms a USB drive has been inserted. If it doesn't appear, reinsert the USB drive. Then touch the **Update** button.

To update the machine's software



 **ONLINE:** For more information about updating the machine's software, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.


 **IMPORTANT:** The Infinity 28 uses the Pro-Stitcher Display which is updated through the Pro-Stitcher, not the machine. Make sure you are also using the latest version of Pro-Stitcher.

 **NOTE:** The Infinity 28 has two required software updates: Infinity 28 Control Board v2.xx and Infintiy 28 Tension Board v1.xx. Both updates must be downloaded and installed to ensure proper functionality.


1. Insert the USB drive into one of the USB ports on the left side of the machine display. Then touch the machine icon to update the machine's software.



2. You will be prompted to choose the file you want to use to update the machine software. Touch the **Select Version** box and then select the filename of the update file you downloaded.



3. Be patient as this will take a few minutes.




4. When done, the lights will flash and the Infinity 28 will reboot.

Diagnostics

There are several diagnostics tests that you may be asked to perform by Handi Quilter technical support or authorized Handi Quilter retailers. They will give you a code to enter into the Diagnostics screen to be able to perform the tests.

- Touch the **Tools** button in the toolbar. Then touch the **Diagnostics** button along the bottom of the screen. Enter the code you receive from Handi Quilter technical support, and follow their instructions for the different diagnostics tests.




Contact your local retailer or Handi Quilter technical support at +1 (801) 292-7988 or 1-877-MY-QUILT (697-8458).

Machine Settings

To open the machine settings, touch the **Settings** icon in the toolbar. After selecting it, the icon turns dark purple.




Then choose one of the seven options that appear along the bottom of the screen (shown on next page). After you select an option, the button turns to dark purple and the screen changes for you to do the configuration of that setting. The next time you touch the Settings icon, the last Settings option you used appears.



- Press the **Home** icon in the upper left corner of the screen to close **Settings** and return to the Main screen.

Easy-Touch Tension™ Presets


You can configure top-thread tension presets for three types of thread. For example, one setting might be for a 50-weight thread, one for a 30-weight thread, and one for monofilament thread. After you establish the tension presets, select the tension setting to use on by pressing the Home button to main screen, then settings, then tension button as shown below. Select the desired setting either, 1, 2, or 3.



To customize the Easy-Touch Tension™ presets

As described in Bobbin and Bobbin Tension in the Using Your Machine section of this manual, make sure your bobbin tension is properly set before adjusting the top tension.

Thread the machine with the thread for which you want to define a top-thread tension preset. Follow the steps for setting the top-thread tension (see Easy-Touch Tension™ in the Using Your Machine section of this manual). When you are happy with the stitching, note the tension value on the Electronic Tension Button and follow the steps below to save it as a preset.



1. Touch the **Settings** icon in the toolbar. Then touch the **Configure Tension Presets** button to open the Tension Presets screen.

2. Press the plus (+) or minus (–) buttons to increase or decrease the settings for one of the three settings until it matches the tension value you want to use. (You should have already tested the tension to determine the correct value for that type of thread.) Then press Home to return to the Main screen.

 **NOTE:** You can also touch the number box for the setting and directly enter the number using the pop-up number pad. Then press **Done** to close.

- On the Main screen, touch the **Easy-Touch™ Tension** button and then select the preset you want to use. Further fine tune the tension using the plus (+) or minus (–) buttons on the screen.




 **NOTE:** After you select a tension preset, you can also use the plus (+) or minus (–) buttons on the handlebars to adjust the tension. Each press on the handlebar buttons changes the tension value by two, whereas each press of the onscreen plus (+) or minus (–) buttons changes the tension value by one. You will not be able to use the handlebar buttons to adjust speed or stitch length while the Easy-Touch Tension button is selected, or while setting tension presets.

Low-Bobbin Alarm

The amount of thread that fits on a bobbin varies according to the type and weight of thread you use. You can create a low-bobbin threshold for up to twenty types of thread that you use in your bobbin. You'll then use this threshold for setting a low-bobbin alarm to alert you to when the bobbin thread is running out.

- Touch the **Settings** icon in the toolbar. Then touch the **Low-bobbin Alarm** button.



To add new bobbin configuration and record bobbin capacity

1. When you are ready to define a new bobbin capacity for a particular type of thread, completely fill a bobbin with that thread and insert it into the machine.

2. Touch the icon to add a new bobbin. Use the pop-up keyboard to enter a descriptive name so you will know which type of thread this configuration applies to. Close the pop-up keyboard by touching arrow in the lower-left corner of the screen.



3. Touch the Record button. The bobbin capacity value will reset to zero. Quilt until the bobbin runs out.



 **NOTE:** The Reset Bobbin button on the Main Screen shows the bobbin capacity as you quilt. When you touch the Reset Bobbin button, it shows the estimated capacity of the full bobbin. As you quilt, this number counts down. While you are recording the bobbin capacity of a bobbin, the number increases as you quilt until it runs out of thread.


4. Return to the low-bobbin alarm screen and press the Record button again to stop recording. The number that appears in the Bobbin Capacity box is an estimate how much thread is on the bobbin.



5. Estimate how much bobbin thread you think you'll use for tieoffs and decrease the bobbin capacity by that much. Press the minus (–) button to decrease the capacity. Or, touch the Bobbin Capacity box to pop up an onscreen number pad and enter the number directly.



6. When you are ready to use a full bobbin with that type of thread, insert the full bobbin and press the Reset Bobbin button on the Main screen



7. Make sure the alarm icon is enabled (green), or on. If not, touch the alarm icon to toggle it on. When the bobbin level reaches zero, the low-bobbin alarm will sound if it is turned on.



 **NOTE:** If you turn on or off the low-bobbin alarm on this screen, it is also turned on or off on the Alarms screen.

The next time you use one of the threads for which you've set up a low-bobbin threshold, touch the bobbin name box and choose the specified thread name by touching it. Insert a full bobbin with that thread into the machine and press the Reset Bobbin button on the Main screen.

To delete a low-bobbin configuration

- Touch the bobbin name box and choose the specified thread name by touching it. Then touch the **Delete (-) Bobbin** button.

To edit a low-bobbin configuration

- Touch the bobbin name box and choose the specified thread name by touching it. Then touch the **Edit Bobbin** button. Make any changes using the pop-up keyboard.


Handlebar Button Options

Use the handlebar customization settings to confirm your handlebar button choices or to make other customizations as to what the star and diamond buttons on the handlebars will do.

To customize the handlebar buttons

- Touch the **Settings** icon in the toolbar. Then touch the **Configure Handlebars** button. Return to the Main menu at any time by touching the **Home** button. **To switch the left and right handlebar buttons.**
- Press the double-arrow icon in the center of the screen to switch the options available for the left and right handlebars.


 **NOTE:** The button images will no longer match their functions once you change their functions here.



Press to switch the button configurations to match how you want the buttons to perform. The left button image represents the left handlebar; the right button image represents the right handlebar.

- 🔔 **IMPORTANT:** Do not attempt to switch the handlebar stickers. This will damage the switches under them.

To configure the star and diamond buttons on the handlebars



1. Select the down arrow next to the star or diamond to display a drop-down box with the options for the star and diamond buttons.
2. Touch your selection for the button.

The options for customizing the star and diamond buttons are:

Option	Action Performed
None	The button will not perform a function.
Start/Stop	Starts or stops stitching
Needle Up/Down	Performs a half stitch by cycling the needle up or down
Increase	Increases stitching speed
Decrease	Decreases stitching speed
Thread Cut	Cuts the bobbin thread
Increase Tension	Increases (tightens) the top tension
Decrease Tension	Decreases (loosens) the top tension
Tension Quick Release	Releases the top tension
Camera	Displays video from the camera on the front display
Tie Off	Performs a tie-off stitch
X-Channel Lock	Constrains the carriage to stitch a straight horizontal line
Y-Channel Lock	Constrains the carriage to stitch a straight vertical line

Laser Light

The Infinity 28 comes equipped with Class II needle-positioning laser. The laser projects a red dot onto the quilt to show where the needle will enter the fabric.

- △ **CAUTION: LASER RADIATION—DO NOT STARE INTO BEAM. CLASS II LASER PRODUCT.**

Maximum output: 1.0 mW

Wavelength: 650 nm



Laser radiation is emitted from the needle area. The laser aperture is located above the needle area. Do not stare into the beam. Do not point the beam toward any person or animal. Do not use mirrors, magnifiers, or other optical instruments to view the beam. Use the needle laser only as described in this manual.

The needle laser is not a user-serviceable component. Do not remove covers, modify the laser, or attempt to service or replace the laser. Service must be performed only by an authorized Handi Quilter retailer or qualified service technician.

- △ **CAUTION:** Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.
- △ **MISE EN GARDE:** Produit laser de classe II. Cette machine comprend un laser de positionnement d'aiguille de classe II qui projette un point rouge sur le quilt pour indiquer l'endroit où l'aiguille pénétrera dans le tissu. Un rayonnement laser est émis depuis la zone de l'aiguille lorsque le laser de l'aiguille est activé. Ne regardez pas directement le faisceau et ne dirigez pas le faisceau laser vers une personne ou un animal. Utilisez le laser uniquement comme décrit dans ce manuel.

Le laser de l'aiguille a une puissance de sortie maximale de 1,0 mW et une longueur d'onde de 650 nm. Le laser de l'aiguille n'est pas une pièce réparable par l'utilisateur. Ne retirez pas les capots, ne modifiez pas le laser et ne tentez pas de l'entretenir ou de le remplacer. L'entretien doit être effectué uniquement par un détaillant Handi Quilter autorisé ou un technicien de service qualifié.

Mise en garde — l'utilisation de commandes ou de réglages, ou l'exécution de procédures autres que celles spécifiées dans ce document, peut entraîner une exposition dangereuse au rayonnement.

To turn the needle laser on or off

- Touch the **Settings** icon in the toolbar. Then **touch** the Laser button. Touch the light button to turn the laser on or off. Dark purple is on and gray is off.



Adjusting the Needle Laser

1. Locate the Hex Tool L 2mm that came in the Infinity 28 accessory kit.
2. Check a needle for straightness by rolling it on the needle plate and making sure the tip does not wobble. If needed replace the needle with a straight one.
3. Turn on the machine. Make sure the needle laser is turned on in machine settings.

 **NOTE:** The needle laser is normally on during needle up and off during needle down.

4. Place a quilting sandwich under the hopping foot and lower the needle into the fabric to punch a visible hole. Raise the needle so the laser will turn on.

 **NOTE:** It is easier to see a needle hole in some fabrics and colors than in others.

5. Back out the 2 screws in the face cover counter-clockwise with a 2mm hex tool until the laser holder can be moved.
6. The needle laser light point should be aligned into the hole in the quilt fabric.
7. To adjust the laser front to back rotate the holder. To adjust the laser side to side push or pull the holder slightly until it is aligned with the needle hole in the fabric.
8. Re-tighten the two screws in the face covers clockwise.



Alarms

The alarm settings enable you to quickly turn on or off the alarms for the low bobbin, thread breaks, and when you are quilting faster than the stitch regulation can accommodate.

Low-bobbin alarm: Alerts you when the low-bobbin threshold has been reached, indicating you will soon run out of bobbin thread. For more information about the low-bobbin alarm, see Low-Bobbin Alarm above.

Thread-break alarm: Alerts you if the top thread breaks while quilting.

Overspeed alarm: Alerts you if you are moving the machine faster than 100% of motor capacity and therefore are quilting too fast for stitch regulation to work properly. Because of the high speeds of the Infinity 28 can handle, you may never encounter this alarm.



To turn on or off alarms

- Touch the alarm button below the alarm to turn it on or off. It is on when it appears green with the sound-wave symbols. It is off when it appears purple.

Tieoffs


Use tieoffs to begin and end your quilting to ensure the stitching doesn't come out. You can manually do the tieoffs by simply stitching in place for a few stitches, or let the Infinity 28 perform a predefined number of quick, micro stitches for you. You can set the number of micro stitches from 0 to 10.

To configure tieoffs

- 🖱️ **ONLINE:** To see how to tie off the thread when starting and ending quilting watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



- Touch the **Settings** icon in the toolbar. Then touch the **Configure Tieoffs** button. Press the plus (+) or minus (–) buttons to increase or decrease the number of micro stitches in a tieoff.



After you indicate how many stitches are in an automatic tieoff, use the Tieoff button on the Main screen to perform the tieoff. Touch the button and gently move the machine to perform the micro stitches.


Set Language

 **NOTE:** This function may not be implemented in your software. When it is available, you will be able to download and update your machine’s software using the Update function.

The language setting determines the language used on the Infinity 28 information screens. The choices are English, Spanish, French, German, Russian, Portuguese, Japanese, Chinese, Italian.

To select a language

- Touch the **Settings** icon in the toolbar. Then touch the button to set the language. Press the down arrow to display the list of available languages. Touch your preferred language to select it.




Information Screens

The Information option provides system information and quick reference guides about your Infinity 28.

To see the needle and thread chart

For quick reference, the Infinity 28 has an on-screen guide for which size needle is appropriate for different weights of thread.


- Touch the **Information** icon in the toolbar. Then touch the **Needle** button.




To see the machine threading diagram

For quick reference, the Infinity 28 has an on-screen guide that shows how to thread the machine. For more information about threading the Infinity 28, see Threading the Machine in the Using Your Machine section of this manual.


- Touch the **Information** icon in the toolbar. Then touch the **Machine Threading** button.




Select one of the buttons along the left to see close-up diagrams of steps 1 through 3, 4 through 9, and 10 through 13.



4-9




10-13



To monitor system information about your machine

You may need to provide system information to Handi Quilter or an authorized Handi Quilter retailer when purchasing machine accessories or receiving technical assistance.

- Touch the **Information** icon in the toolbar. Then touch the **Information** button in the lower-right corner of the screen.



The screenshot shows the INFINITY28 app interface. At the top is a purple toolbar with icons for Home, Camera, Lightbulb, Wrench, Gear, and Information. Below the toolbar, the app displays system information:

Lifetime Stitch Count: 621
Lifetime Machine Time: 0:00:43

	Hardware Version	Software Version
Control Board:	1.00	1.78
Tension Board:	R0	V1.00
Handlebar Board:	R0	V1.0U?
Display:	VT-TPC12-PS	26.1.900.0

On the right side of the screen, there is a vertical stack of three buttons: a purple button with a white hash symbol (#), a purple button with a white sewing machine icon, and a purple button with a white information icon (i). An arrow points from the text "Opens system information about the machine." to the information icon button.

Machine Maintenance

Clean and Oil Your Infinity 28

The only place where you need to regularly oil your machine is the bobbin hook assembly. Failure to keep the hook assembly lubricated can cause severe damage to the machine. We recommend that you oil the hook assembly with each bobbin change and before use if you haven't used the machine for a few days. A change in the sound of the machine while quilting also indicates that it may need to be oiled.

 **NOTE:** Internal oiling needs to be done when the machine is taken to a service technician for routine maintenance and cleaning, every 24 months or 15 million stitches (whichever comes first).

 **IMPORTANT:** Only use light sewing machine oil in the hook when oiling your machine.

To clean the bobbin area and oil the bobbin hook

 **ONLINE:** To see how to clean and oil the bobbin area, watch the video at <https://handiquilter.com/courses/infinity-28-getting-started/>.



1. Turn off the machine by powering off the front switch. Then remove the bobbin and bobbin case.
2. To clean the bobbin basket area, use canned air. This ensures that you don't damage any of the wires or the bobbin-thread cutter. Any dust or lint will be blown out of the openings surrounding the bobbin basket.

 **IMPORTANT:** Use short bursts of canned air. Be sure to also follow the specific instructions that come with the canned air.

3. Put a small drop of oil on the hook in the region where the bobbin basket assembly and the rotating hook meet. The oil will work its way back into the interlocking area of the hook and bobbin basket.



4. Replace the bobbin and bobbin case and turn on the machine.

Machine Quilting Tip: After oiling your machine

After oiling, always sew on a scrap piece of fabric off to the side of the quilt as oil may cling to thread. Over oiling can cause excess dripping from the bobbin assembly.

To clean the touch-screen display

- Use a soft rag or microfiber cloth and gently wipe the display to remove any dust or fingerprints.

△ **CAUTION:** Never use any chemicals to clean your display as this may negatively affect the display's touch-screen response.

Maintenance Schedule

In addition to the ongoing cleaning and oiling maintenance, you should have your machine serviced by an authorized Handi Quilter retailer every 24 months or 15 million stitches, whichever occurs first. They will take care of oiling and greasing internal parts and ensure the machine is in tip-top working order. When your machine reaches 15 million stitches, a pop-up message appears to remind you to have your Infinity 28 serviced.

Troubleshooting

You can correct many problems on your own. If you need additional help, contact your local, authorized Handi Quilter retailer. You can also contact Handi Quilter technical solutions at 1-801-292-7988 or 1-877-MY-QUILT (697-8458).

First check the following:

1. The AC power cord is properly connected and both power switches are turned on.
2. Confirm that all cables are properly seated into their connections.
3. Turn off the machine completely. Wait for at least ten seconds and then it back on.

If the above checks did not solve the problem, refer to the information below.

Skipped Stitches	Corrective Measure(s)
The needle is damaged, dull, bent, or installed improperly	• Replace the needle often, normally once or twice per day for continuous quilting or at least once per quilt. Use only the recommended needle system. • Always change the needle if the needle has struck any hard object such as a straight pin, etc. The tip of the needle can become damaged or burred, resulting in fabric damage as well as skipped stitches, thread breakage, or shredding. • Always change the needle if it has been hit, bumped or pulled off center while maneuvering the machine about the quilt. A slightly bent needle can be a major cause of skipped stitches.

Incorrect needle size	Use the proper size of needle for the work and thread being used. Some battings and fabrics used in quilting may constrict or impede the thread passing through the front groove of the needle. This diminishes the loop lift required for stitch formation. Typically, a larger needle will solve the problem. However, using certain smaller sizes of needles and ball pointed needles solve some specific problems. You will need to experiment to determine which work best with your combination of fabric, thread, and batting.
Fabric is too tight on the frame	Loosen the pole tension on the frame. Fabric that is rolled too tightly causes the fibers to separate and the fabric to bounce while quilting. This reduces the needle friction on the thread, resulting in a smaller thread loop.
Thread tension too tight	Check bobbin case tension and then check top thread tension. (For more information about adjusting tension, see Bobbin and Bobbin Tension and Easy-Touch Tension™ in the Using Your Machine section of this manual.)
The needle is not positioned properly	- Position the needle properly to the needle bar. Inspect the position of the needle to make sure the needle is at the 6 o'clock position. When you stand directly in front of the needle (facing the bobbin case side of the machine), you will see the entire needle eye directly facing you. This is 6 o'clock position. - Make sure (a) the needle is installed all the way into the needle bar to the needle-stop hole in the needle bar, (b) the long groove in the needle is toward the front (bobbin case side), and (c) the scarf (scooped out part of the back of the needle) is toward the back of the machine. - The needle can sometimes be rotated to 5 o'clock (slightly right) or 7 o'clock (slightly left) to adjust for a more positive thread loop pickup by the hook point.
Improper threading	Ensure that the machine is threaded correctly.
The Needle Breaks	Corrective Measure(s)
The needle is bent or not installed properly	Replace the needle. Make sure that the needle is pushed into the needle bar clamp until it can go no farther. Visually check that it is up to the top of the stop/sight hole above the needle bar clamp screw. If the needle isn't installed properly, it can cause damage in the bobbin area and throat plate.
The needle hits the throat plate	Correctly position the needle, throat plate, or hopping foot. Replace with a new needle.

Stitches are Puckered	Corrective Measure(s)
The tension is not balanced	Balance the tension of the needle thread after ensuring the bobbin tension is adjusted correctly. (For more information about adjusting tension, see Bobbin and Bobbin Tension and Easy-Touch Tension™ in the Using Your Machine section of this manual.)
Needle too large for quilting fabric	Replace the needle with a size better suited for the fabric. Always match your needle size to your thread weight.
Poor Stitch Quality	Corrective Measure(s)
The tension is not balanced	Balance the tension of the needle thread after ensuring the bobbin tension is adjusted correctly. (For more information about adjusting tension, see Bobbin and Bobbin Tension and Easy-Touch Tension™ in the Using Your Machine section of this manual.)
Bobbin case is damaged, corroded, dirty, etc.	Since thread slides over the surface of the bobbin case at a high speed, make sure the case is free of any lint or foreign matter that could impede thread passage through the machine.
Moving the machine too fast for needle speed selected (Manual mode)	Synchronize machine movement and needle speed to get roughly 8 to 10 stitches per inch. Elongated stitches are an indication of moving the machine too fast for the current speed.
Tension is Poor	Corrective Measure(s)
Lint caught under the tension spring in the bobbin	If using short staple threads, inexpensive, or industrial threads, or coated threads, lint and other material will build up under the tension spring and begin to lift the spring, reducing the spring's ability to compress against the thread. Insert a needle or business card under the spring and clear out the lint. The bobbin tension will return fairly close to its preset tension. Test the tension before quilting.
Hand Wheel Won't Rotate	Corrective Measure(s)
Thread is entangled and caught in the hook	There may be a thread lock. With the machine on, use the on-screen hand wheel to break the thread lock. Quickly move your finger down and up several times. If this doesn't solve the problem, turn the machine off and use the handwheel at the back of the machine to resolve the thread lock.
Thread Nests Under Quilt	Corrective Measure(s)

Not enough tension on top thread	Check that the machine is threaded correctly. Make certain that the thread is flossed snugly in place between the two tension discs. If the machine is threaded correctly, tighten top tension by rotating the tension knob clockwise. (For more information about adjusting tension, see Bobbin and Bobbin Tension and Easy-Touch Tension™ in the Using Your Machine section of this manual.)
Improper threading	Refer to threading diagram and threading instructions.
Thread Backlash	Corrective Measure(s)
Bobbin thread tangles within the bobbin case, tangles and winds onto the hook spindle, or occasionally forms loops on the bottom of the quilt.	The bobbin should sit in the bobbin case such that one side is very minimally above the edge of the bobbin case and if you lightly press down on the bobbin, it descends slightly into the case. To adjust the backlash spring, place the bobbin in the case and hold it with the bobbin facing up. Then use a tiny screw driver to adjust the screw on the outside front shiny surface of the bobbin case (not the screw inside the bobbin case). Turn the screw counterclockwise to raise the backlash spring (and raise the bobbin) or turn it clockwise to lower the backlash spring (and lower the bobbin). After making an adjustment, reinsert the bobbin into the machine, bring up the bobbin thread, and test stitching. Make additional adjustments if necessary.
Hard to Guide Machine	Corrective Measure(s)
Carriage wheels not centered on track	Center the carriage wheels on top of the continuous track. Check that the machine carriage has not jumped the track.
Thread caught in wheels	Remove all thread or debris in wheels. Check that the tracks are free of lint and threads.
Motor Fails to Run	Corrective Measure(s)
On/Off switch turned off	Make sure that both power switches are turned on. First turn on the rear power switch (to the 1 position); then turn on the red power button on the front-left side of the machine.
Machine not receiving power	Check that the power connector is securely plugged into the back of the machine and the three-prong end is plugged into the power source.
Uneven Quilt Design	Corrective Measure(s)
Take-up rollers may be bowed or bent	Make certain the fabric is not rolled too tight, causing the poles to bow. Check that poles are inserted completely together with the push pins engaged so bowing won't occur.

Leaders are stretched or worn	If fabric is beginning to stretch or fray, contact Handi Quilter to purchase replacement leaders.
Thread Breaks	Corrective Measure(s)
Thread is poor quality or may have severe twisting or thread rot	Look for severe twisting of threads when approximately 12 to 15 inches has been pulled off, with the ends pinched together. Cotton threads are particularly susceptible to dry rot or wet rot which makes thread brittle. Do not use poor quality thread, or thread that is rotted or brittle.
Top and bobbin tensions not balanced	Balance the tension of the needle thread after ensuring the bobbin tension is adjusted correctly. (For more information about adjusting tension, see Bobbin and Bobbin Tension and Easy-Touch Tension™ in the Using Your Machine section of this manual.)
The machine head has been threaded incorrectly or thread spools are not positioned correctly	- Check that the machine is threaded correctly. - Inspect for accidental double wrapping of thread on thread guides. - Inspect the thread mast, making sure the eyelets of the mast are directly over the spools. - Inspect the vertical positioning of the thread cones. Tipped cones can dramatically affect thread tension and can cause breakage.
Debris in tension discs	Inspect for particles and remove any fuzz or debris.
Bobbin rotation is not smooth	Change the bobbin. The slightest hesitation of the bobbin rotation can be the cause of dramatic tension change and thread breakage.
Needle is burred, bent or dull, or installed incorrectly	Change the needle at least once per quilt. Make sure the needle is installed to the top of the stop hole in the needle bar.
Needle not suitable for thread	Replace the needle to one better suited for the thread. Use the proper size needle.
Hesitating too long at one point in quilting motif	Move more quickly so stitches don't overlap or build up. When starting the machine, begin moving immediately. Sewing in one place too long will cause the thread to break.
Improper needle/hook relationship	Machine timing needs to be checked. Consult an authorized Handi Quilter technician.

Damage or burr at needle hole of throat plate or other thread handling part	• If thread is shredding at the throat plate, check for burrs or jagged edges. Gently rub with metal cloth to remove the sharp edge. Consult a repair technician to polish any hard-to-reach or delicate areas, or if the burr is inside the throat.
Wrong type of needle	• Use only the needles recommended by Handi Quilter (134 MR, sizes 12 through 21).
Other possible problems	• Needle too close to hook, causing friction and possible collision of hook point and needle (causing broken thread). • Needle plate damage • Hook damage • Broken needles or damaged needle bar clamp
Nothing visible on the display	Corrective Measure(s)
Display not powered on	• Press the power button on the right side of the display (top button on the right side of the display).
Display cable unplugged	• Locate the black USB Type C cable exiting the front of the quilting machine and plug it into the left side of the display.
Display battery dead	• With the USB C cable plugged into the display and the rear power switch in the ON position, press the quilting machine front power button to power on the machine. This will turn on the quilting machine and start charging the display tablet. A green LED indicator at the top left of the display shows it is being charged. Press the power button at the top right of the display to now turn on the display.
“Motor error initializing communications” message when powering up display or starting Pro-Stitcher application	Corrective Measure(s)
Loose or disconnected Pro-Stitcher data cable	• Ensure the data cable is plugged into the round connector at the rear of the machine and that the metal threaded end of the cable is properly threaded into the machine connector.
	• You may need to push inward on the cable toward the machine while twisting the metal cable connector to get the threads to catch.
	• If you cannot push the cable inward far enough to get the threads to catch, check the cable to make sure the line molded into the cable connector is pointed upward.

Pro-Stitcher power cord disconnected	• Ensure the Pro-Stitcher carriage power cord is plugged into the wall and that the other end is properly seated in the Pro-Stitcher carriage power inlet. If it is plugged in, you should see some LEDs on the top of the Pro-Stitcher carriage.
USB C cable disconnected from display	• Ensure the USB C cable at the front of the quilting machine is plugged into the left side of the display.

 **NOTE:** If the troubleshooting tips do not eliminate the problem, please consult an authorized Handi Quilter Retailer.

Appendix 1

Federal Communications Commissions (FCC) Declaration of Conformity (For USA Only)

Responsible Party: Handi Quilter, Inc.
501 North 400 West
North Salt Lake, UT 84054

declares that the product

Product Name: Infinity 28

complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the manufacturer or local sales distributor could void the user's authority to operate the equipment.

Canadian Department of Communications Compliance Statement (For Canada Only)

This digital apparatus does not exceed the Class B limits for radio noise emission from digital apparatus as set out in the interference-causing equipment standard entitled "Digital Apparatus", ICES-003 of the Department of Communications.

Radio Interference (Other than USA and Canada)

This machine complies with EN55022 (CISPR Publication 22) /Class B and AUS/NZ 55022/Class B.

Appendix 2: QR Codes for Infinity 28 Videos

The following QR codes enable you to use your smart phone to quickly load the Infinity 28 Getting Started videos. Download a QR reader from the application store for your phone. Then use the QR reader to scan the QR code. The video will then play on your smart phone.

BILT APP



Infinity Manual Videos



Warranty issues should, whenever possible, first be submitted to the Authorized Retailer who completed your service and training. These Retailers have been selected for their dedication to customer satisfaction and have been trained in technical service. They also may provide follow-up advice, training, service, accessories, and other services.

Handi Quilter Authorized Retailers may offer their own warranties in addition to those offered by the manufacturer, but do not obligate the manufacturer.

Handi Quilter Quilting Machine Limited Warranty

Handi Quilter, Inc. (hereinafter HQ) offers a limited warranty on the HQ Quilting Machine (hereinafter “Machine”) to be free of defects in workmanship and materials under normal use upon the terms and conditions hereinafter set forth:

- (a) **90 day Limited Warranty:** During the first 90 days from date of purchase, Handi Quilter will repair any manufacturing defect without charge for parts or labor. All subsequent warranties include parts costs only.
- (b) **5-year Mechanical Warranty:** For any mechanical failure within this period. Manufacturer will provide free replacement parts, customer pays for labor and shipping.
- (c) **5-year Electronic/Electrical Warranty:** The electric/electronic components are warranted to be free from manufacturing defects for five years from the date of purchase. If any defect is reported within this period, manufacturer will provide free replacement parts, customer pays for labor and shipping. The 5-year electronic/electrical warranty will be invalid if the machine is left plugged into a power source when not in use.
- (d) **10-year Limited Manufacturer’s Warranty:** HQ warrants the sewing head is free of casting or machining imperfections causing product failure. This warranty does not extend to mechanical or electronic/electrical parts, which are covered under a separate warranty, or consequential damage to the head caused by mechanical or electronic/electrical part failures beyond their warranty period.

The limited warranty stated in sections (b), (c) and (d) above shall be limited solely to the replacement of parts which, in the opinion of HQ, are defective in workmanship or material and are returned to HQ, or an authorized repair facility, or such other point or place that may be designated by HQ. All other costs, including cost of freight and shipment for repair under this warranty, shall be the customer’s costs.

The machine registration card must be completed and received by HQ before warranty is valid.

Warranty Exclusions: HQ shall have no obligation for any claim under this warranty if the machine has been misused, abused, neglected, damaged in transit or has been altered from the standard specifications established by HQ, or if proper maintenance and lubrication have not been timely performed.

No warranties extend beyond the express warranty offered. HQ disclaims all other warranties, express or implied, regarding the Products, including any implied warranties of merchantability or fitness for a particular purpose. In the United States, some laws do not allow the exclusion of the implied warranties.

Specific exclusions of warranty limitations include, but are not limited to, the following:

- General, consequential, incidental or special damages including damage to fabric or material, the cost of rework or lost profits, the cost of installation or removal of any Products, and any inspection, testing, or redesign caused by any defect or by the repair or replacement of Products arising from a defect in any Product.
- Products which are received by HQ improperly packaged, altered, or physically damaged.
- Counterfeit or altered label(s) or stickers.
- Broken pins on connectors.
- Stripped screws or nuts.

- Connector(s) damaged, cracked, missing or broken.
- Missing, torn or punctured seal(s).
- Any use besides machine quilting applications using customary fabrics, threads and accessories.
- Operator error in the customary use of the Product.
- Internal adjustments, tampering or parts replacement done by anyone except authorized Retailers or customers specifically authorized by Handi Quilter Customer Support or warranty repair personnel on a case by case basis.

The warranty does not cover and the user assumes the risk of and there is hereby excluded any liability to HQ for failure, defects, loss, deterioration, personal injury or damage which are due to: (1) ordinary wear and tear or exposure, (2) abuse, misuse, negligence, or (3) use of parts not authorized by HQ.

In no event shall HQ be liable to the purchaser of the Machine or to third parties for special or consequential damages, including, but not limited to, death or personal injuries.

HQ does not assume, or authorize any person to assume on its behalf, any other obligation of liability other than that set forth herein.

Some states do not allow exclusion of limitation of incidental or consequential damages, so above limitation or exclusion may not apply. This warranty gives the purchaser specific legal rights and the purchaser may also have other rights, which may vary for State to State.

Exclusive Remedy: Remedy is limited to the repair or replacement of the defective Product. HQ may elect which remedy or combination of remedies to provide at its sole discretion and shall have a reasonable time, after determining that a defective Product exists, to repair or replace the defective product. Replacement Product may be from new or serviceable used parts. HQ's warranty applies to repaired or replaced Products for the balance of the applicable period of the original warranty or ninety days from the date of shipment of a repaired or replaced Product, whichever is longer.

HQ's entire liability for any defective Product shall in no event exceed the purchase price for the defective Product. This limitation applies even if Handi Quilter cannot or does not repair or replace any defective Product.

Service under the above warranties may be obtained by returning the quilting machine, with proof of purchase, to the authorized Retailer from whom the machine was purchased, a local Retailer, or to Handi Quilter Customer Support.

Any product to be returned to the factory, either by customers or Retailers, must be accompanied by a Return Material Authorization Number (RMA). RMAs may be obtained by email (sales@handiquilter.com) or by calling customer support toll free at 1-877-697-8458. If it is determined that the Product may be defective, an RMA number will be issued with instructions for Product return. An unauthorized return (a return without an RMA number) will be shipped back to customer at customer's expense. Authorized returns are to be shipped prepaid and insured in an approved shipping container. The original box and packaging materials should be kept for storing or shipping.

Shipping Costs: Shipping is the responsibility of the customer.


Product Service and Maintenance: Replace needles every 2 to 4 hours (1 to 2 per large quilt) and lubricate bobbin hook every 3 to 4 hours of use. Periodically check the thread tensioner. Use canned air to clean out all lint, loose thread, or obstructions from the bobbin hook.

Servicing is recommended annually from a qualified HQ Retailer. Servicing will cover belt tensioning, encoder positioning, bearing retainers, hook axial play and timing, presser and needle-bar adjustment and internal lubrication to take-up lever, hopping foot levers, bushings/bearings.

Handi Quilter, Inc.
Customer Relations
501 North 400 West
North Salt Lake, Utah 84054

HANDI QUILTER WARRANTY REGISTRATION

Online warranty registration is available at **HandiQuilter.com/machine-registration** (or scan QR code to take you to the link), but you may also mail or fax completed this Warranty Registration card **within 30 days of purchase**. If you have questions, email HQCares@HandiQuilter.com or call Customer Relations at 1-877-697-8458.



MAIL TO: Handi Quilter, Inc.

Warranty Registration Dept.

501 N 400 W

North Salt Lake, Utah 84054

FAX TO: 801-294-3011

The HQ Quilting Machine warranty is 10 years manufacturer's warranty on casting and machining of the case, 5 years electronic/electrical, and 5 years mechanical. Check with your local HQ Retailer for details on service or making warranty claims.

HQ Quilting Machine Model (check one):

☐ Moxie™ ☐ Moxie™ XL ☐ Simply Sixteen®

☐ Amara® ST ☐ Amara® 20 ☐ Amara® 24 ☐ Infinity 28®

Customer Name: _____

Company/Business Name (if applicable): _____

Address: _____

City, State, Zip: _____

Daytime Phone: _____ Evening Phone: _____

Fax: _____ Email: _____

HQ Serial Number: _____ Order Number (5 digits): _____

Purchase Date: _____ Date Machine Received: _____

Location of Purchase (Shop or Show name, City & State): _____

Type of use intended: ☐ Home/Personal ☐ Some commercial ☐ Share w/Friends ☐ Mostly commercial

☐ Other _____

Type of machine-quilting skills: ☐ Novice ☐ Intermediate ☐ Experienced

Skill at adjusting sewing machines: ☐ Novice ☐ Intermediate ☐ Experienced

Signature: _____ Date: _____

Infinity 28 New Owner and Training Checklist and Certificate

Handi Quilter

You are entitled to a one-time free introductory training class on the use of your Handi Quilter quilting machine as well as free adjustments for 60 days and any repairs covered by the warranty. Present this checklist to your authorized Handi Quilter quilting machine Retailer to receive these free services.

Retain a copy for your records.

Frame

- ☐ How to adjust length
- ☐ How to adjust height
- ☐ How to change from Standard load to Clearview load
- ☐ Ensure the frame is level

Machine Setup

- ☐ Identify the main parts of the machine
- ☐ Ensure machine is properly placed on the carriage
- ☐ Check all cable connections
- ☐ Ensure power outlet is available and does not cause a trip hazard
- ☐ Recommend and explain the importance of a power strip with surge protection
- ☐ How to wind a bobbin (including how to adjust the tension and the capacity)
- ☐ How to load a quilt in both Standard and Clearview modes
- ☐ How to adjust the handlebars

Machine Operation

- ☐ How to turn the machine on and off (both switches)
- ☐ How to change the needle
- ☐ How to change the Handi Feet
- ☐ How to properly thread the machine
- ☐ How to set the bobbin tension; teach the drop test
- ☐ How to set the upper tension with Easy-Touch Tension
- ☐ How to bring up the bobbin thread
- ☐ How to tie off (manually and with auto tie-off)
- ☐ How to use the menus: explain each menu
- ☐ How to adjust lighting
- ☐ How to use the on-screen handwheel
- ☐ How to set and use the low bobbin estimator
- ☐ Explain timers and stitch counters
- ☐ How to switch between stitch regulation and manual mode
- ☐ How to set the speed in manual mode; how to set the presets
- ☐ How to set the stitches-per-inch in stitch regulation
- ☐ How to use Cruise stitch regulation
- ☐ How to use Precision stitch regulation
- ☐ How to use the handlebars (including setting options for programmable buttons)
- ☐ Explain the alarms

Machine Maintenance

- ☐ How to oil the bobbin hook: where, how, and when
- ☐ How to clean the bobbin hook area
- ☐ How to clean wheels and tracks

IMPORTANT: Read before signing

By signing this training checklist you are acknowledging you have been personally instructed in the operation of the Infinity 28 machine you purchased. Additional training by this Handi Quilter Retailer or any other Handi Quilter Retailer may result in being charged for additional instruction.

Customer Name _____

Customer Signature _____

Training Date _____

Trainer Name _____

Retailer Signature _____

HQ Retailer Business Name _____

Business City and State/Province _____

Purchase Date _____

Machine Serial Number _____

Pro-Stitcher Serial Number _____

Handi Quilter Retailer: To register training services provided, return completed and signed certificate by FAX (1-801-294-3011) or MAIL:

Handi Quilter
501 North 400 West
North Salt Lake, UT 84054

OR email to your customer relations coordinator.