

CAUTION!!! Looking directly into the UV lights or prolonged exposure to the UV lights can damage your eyes. Limit the use of the UV lights to avoid permanent eye damage. Use of UV A/B blocking sunglasses will reduce eye strain and limit the effects of prolonged exposure to UV lighting.

CAUTION!!! Users who have had cataract surgery should not use the UV lighting unless they have had UV A/B blocking replacement lenses implanted as part of the surgery.

REMEMBER!!! Always turn off power to the machine before installing LED modules. Damage to the module or machine may result from not following this directive.

Installation

1. Please remember to turn off your HQ¹⁸ Avanté before installing your UV LED lights.

2. UV LED lights will be installed in the row used for the ‘Spotlight’ setting.



3. Remove any lights that may be in the innermost three slots on both sides of handlebars and place them in empty slots according to your preference

4. Install 3 UV LED lights on the three innermost slots on your HQ¹⁸ Avanté handlebars. Repeat on both sides of the handlebar.

5. To use UV LED lights, turn ‘Main Lights’ off and turn ‘Spotlights’ on.