

Handi Hammock

(HG12000)

Assembly Instructions for Studio 3 Frame

Parts Needed: Item C, Knurled Thumb Screw (8mm) x2 

Step 1: Place one item C, Knurled Thumb Screw (8mm), into the back pre-threaded accessory mount on the bottom of the side arm assembly as shown. This will hold the rear hammock cord loop.

Step 2: The front hammock cord loop will use the existing knob located on the outside of the side arm assembly.

Step 3: Repeat the process on the other end of the frame.

