Pro-Stitcher® COMPARISON GUIDE

Pro-Stitcher Premium and Pro-Stitcher Lite computerized quilting systems offer quilters the ability to do what they love, faster. While the two systems are similar in their function, there are several differences between the two. This guide outlines features and HQ compatibility.

	PRO-STITCHER LITE	PRO-STITCHER PREMIUM				
System Features						
	✓ (11 inches)	✓ (12 inches)				
Color touchscreen tablet (Included as part of robotics system)						
Computer-guided and Free-motion Quilting	✓	~				
Tablet Integration*		✓				
Cable Integration*	✓	✓				
Digital Designs Included	250	800+				
Pro-Stitcher Designer Design Software	✓ Available	✓ Included				
Software Features						
Simulation Mode	~	✓				
Free-Motion Record + Save		✓				
Create, Position, and Quilt Designs	✓ Condensed settings	✓				
Channel Locks (horizontal + vertical)	~	✓				
Tie-off Settings	✓ Set increments	✓				
Wrap Designs	✓ Set increments	✓				
Warranty (mechanical/electrical)	5yr/5yr	5yr/5yr				

SOFTWARE FEATURES		PRO-STITCHER LITE	PRO-STITCHER PREMIUM
	Workspace, Save + Open		✓
GENERAL	Load multiple designs	✓	✓
	Needle Drag + Drop	✓	✓
	Follow		✓
	Zoom	✓	✓
O	Pan	✓	✓
	Select	✓	✓
	Undo/Redo	✓	✓
	Skew 1, Skew 2 (border), Skew 3 (triangle)	✓ Limited options	✓
	Mirror + Flip patterns	✓	✓
	Rotate patterns	✓	✓
	2-point rotation		✓
	Custom rotation	✓	✓
	Align	✓	✓
	Reposition + Nudge	✓	✓
	Reposition: Start Point	✓	✓
	Reposition: Current + End Point	✓	✓
MODIFY	Reposition: Center	✓	✓
9	Reposition: Drag + Drop	✓	✓
2	Reposition: Zero		✓
	Reposition: top/bottom, left/right	✓	✓
	Resize	✓	✓
	Crop - inside / outside	✓	✓
	Crop - edges	✓	✓
	Crop - start / end	✓	✓
	Swap start + end points	✓	✓
	Baseline	✓	✓
	Transform, xform		✓
	Basic Repeat	✓	✓
	P2P basic	✓	✓
	Fill	✓	✓
	Stretch	✓	✓
EAT	Horizontal + Vertical Gap	✓	✓
REPEAT	Wrap, Window	✓ Set increments	✓
LE.	Wrap, Row	✓ Set increments	✓
	Wrap, Gap	✓ Set increments	✓
	Wrap: edges, drag		✓
	Wrap: no wrap	✓	✓
	Rubber band		✓
VIEW	Design	✓	✓
	Area	✓	✓
	Rulers / Grid	✓	✓
	Design Points		✓
	Start + End	✓	✓
	Jumps	✓	✓
	Bounds		✓
	Scroll	✓	✓
	Transparency		✓

SOFTWARE FEATURES		PRO-STITCHER LITE	PRO-STITCHER PREMIUM
	Free-Motion Record + Save		✓
PRO-STITCHER	Mark + Clear	✓	✓
	Half Stitch	✓	✓
	Full Stitch	✓	✓
	Follow		✓
1	Measure	✓	✓
-ST	Baste		✓
RO	Channel Locks Horizontal/Vertical	✓	✓
<u> </u>	Move	✓	✓
	New Start + End	✓	✓
	Auto Stat + End	✓	✓
	Push button release of gears	✓	✓
	2-pt area	✓	✓
∢	Multi-point area	✓	✓
AREA	Manual numeric area dimension adjustment	✓	✓
•	Quilting/hoop space	✓	✓
	Rubber band to area		✓
	Stitch	✓	✓
-	Tie offs, start + end	✓	✓
QUILT	Pullup options	✓ Set increments	✓
σ	Trace Bounds		✓
	Trace Area	✓	✓
	Nudge defaults	✓	✓
	Auto Jump defaults	✓ Set increments	✓
	Opti-Stitch	✓	✓
	Stitches-per-inch setting	✓	✓
	Baste setting		✓
lGS	Tie-off number setting	✓ Set increments	✓
SETTINGS	Tie-off distance setting	✓ Set increments	✓
SET	Tie-off start + end setting	✓ Set increments	✓
	Tie-off tack		✓
	Tie-off micro	✓ Set increments	✓
	Pullup preferences	✓ Set increments	✓
	Pause Delay preferences (time + distance)		✓
	Stitch Stats		✓
	Simulation Mode	✓	✓
	General, thread break sensor*		✓
	General, verify before quilt	✓	✓
	General, Keep Motors Locked		✓
G	General, Load start point at crosshairs		✓
N	General, Load Point to Point		✓
ADVANCED	Communications, PS	✓	✓
	Communications, Reconnect Motors	✓	✓
	Communications, Reconnect Machine	✓	✓
	Speed Profile, Max SPM	✓	✓
	Logging preferences	✓	✓
	Motors, Motor Torque Limit	✓	✓