
# Stationary Longarm Table Drawer **Assembly Instructions**



## **Table of Contents**

- 2 Whats Included, Replacement Parts and Hardware
- 4 Attaching Drawer Front Face
- 5 Attaching Slide Rails to Table
- 6 Installing and Adjusting the Drawer

#### Introduction

The Stationary Longarm Table Drawer can be installed on the left, right or both sides of the table.

## What's Included with the Stationary Longarm Table Drawer

# **Replacement Parts and Hardware**

QT09000-801	SD Drawer Base
QT09000-803	Slide Rail, Left
QT09000-802	Slide Rail, Right
QT09000-805	Drawer Slide, Left
QT09000-804	Drawer Slide, Right
QT09000-806	SD Drawer Front Face
QM10347	Screw-6-32 X 5/16 PHF ZN
QM10348	Screw-M3.5 X 8 PHP W ZN
QM10344	Screw-6-32 X 1/4 PHF ZN
QM10346	Nut-6-32 Nylock ZN
QM10345	Screw-6-32 X 1/4 PHP ZN
QT09000-608	Washer-M8X24mm OD ZN
QT09000-605	Screw-M8x1.25X45mm SKB ZN
	QT09000-803 QT09000-802 QT09000-805 QT09000-804 QT09000-806 QM10347 QM10348 QM10344 QM10346 QM10345 QT09000-608

Hex Key L 5mm


**Tools Needed** 

1 QM10289


- 1 Hex Key L 5mm (Provided)
- 1 Screwdriver #2 Phillips Head (Not Provided)




Hex Key L 5mm (1) QM10289



SD Drawer Base (1) QT09000-801



Slide Rail, Left (1) QT09000-803




Slide Rail, Right (1) QT09000-802



Drawer Slide, Left (1) QT09000-805



Drawer Slide, Right (1 QT09000-804



SD Drawer Front Face (1) QT09000-806



Screw--6-32 X 5/16 PHF ZN (10) QM10347



Screw-M3.5 X 8 PHP W ZN (4) QM10348




Screw-6-32 X 1/4 Phillips Flat Head(8) QM10344




Nut-6-32 Nylock ZN (20) QM10346



Screw-6-32 X 1/4 PHP ZN (2) QM10345




Washer-M8X24mm OD ZN (4) QT09000-608



Screw-M8X1.25X45 SKB ZN (4) QT09000-605

# **Attaching the Drawer Front Face**

1. Attach the drawer front face with the four wood screws and fully tighten them with a #2 Phillips screwdriver.




Note: The two holes closest to the edge go up.

# **Attaching Slide Rails to Table**

- 1. Position the left slide rail with the wheel to the front. Place it on top of the table cross bars with the drawer slide wheel to the right (inside).
- 2. Insert the two screws with large washers up through the crossbars and into the drawer slide.
- 3. Tighten the two screws leaving them a little loose to allow adjustment later on.
- 4. Position the right slide rail with the wheel to the front. Place it on top of the table cross bars with the drawer slide wheel to the left (inside).

5.Repeat steps 2 and 3 for the right drawer slide.



# **Installing and Adjusting the Drawer**

1. Tilt the front of the drawer down about 60 degrees. Align the two drawer wheels and guide them up over the wheels on the slide rails.

2. Lift the front of the drawer up and into the slide rails.

3. Push the drawer all the way in.

4. Slide the drawer in and out a few times to ensure it moves freely.

5. Fully tighten the four large screws using the provided 5mm L hex tool.

6. The drawer should slide freely in and out of the slide rails at this point; if not, you may need to loosen the four large screws, align the slide rails and then re-tighten the screws.

