

HQ Sweet Sixteen Table Overlay Installation Instructions

CAUTION: This process results in a permanent installation. Removing the overlay may result in the separation of the white melamine from the table surface. Should you wish to protect the table surface, we suggest placing clear packing tape on the tabletop first, then applying the double-stick tape to the packing tape. Removal of the packing tape may leave traces of adhesive behind, requiring the use of an adhesive-removal substance.

If the HQ Sweet Sixteen must be removed after the table overlay is installed, lift the machine upward at the back a couple of inches so the needle plate drops below the table overlay. Then proceed to pull the HQ Sweet Sixteen out of the back of the table.

1. Remove the pink protective plastic from the tape on **ONE SIDE ONLY** of the table overlay.
2. Slide the table overlay (*with the tape-side down*) under the HQ Sweet Sixteen hopping foot and align the overlay while holding the side up with the exposed tape.
3. When the overlay is in position, begin pressing down the side of the overlay with the exposed tape, making sure the overlay is still positioned properly.
4. With one side stuck to the table, lift the opposite side of the overlay to remove the pink protective plastic from the tape.
5. Carefully press the overlay down, adjusting as needed.



877-697-8458 or 801-292-7988
445 N 700 W, North Salt Lake, Utah 84054
www.HandiQuilter.com

HQ Sweet Sixteen Table Overlay Installation Instructions

CAUTION: This process results in a permanent installation. Removing the overlay may result in the separation of the white melamine from the table surface. Should you wish to protect the table surface, we suggest placing clear packing tape on the tabletop first, then applying the double-stick tape to the packing tape. Removal of the packing tape may leave traces of adhesive behind, requiring the use of an adhesive-removal substance.

If the HQ Sweet Sixteen must be removed after the table overlay is installed, lift the machine upward at the back a couple of inches so the needle plate drops below the table overlay. Then proceed to pull the HQ Sweet Sixteen out of the back of the table.

1. Remove the pink protective plastic from the tape on **ONE SIDE ONLY** of the table overlay.
2. Slide the table overlay (*with the tape-side down*) under the HQ Sweet Sixteen hopping foot and align the overlay while holding the side up with the exposed tape.
3. When the overlay is in position, begin pressing down the side of the overlay with the exposed tape, making sure the overlay is still positioned properly.
4. With one side stuck to the table, lift the opposite side of the overlay to remove the pink protective plastic from the tape.
5. Carefully press the overlay down, adjusting as needed.



877-697-8458 or 801-292-7988
445 N 700 W, North Salt Lake, Utah 84054
www.HandiQuilter.com