# **MOXIE** BY HANDI QUILTER

#### OWN. EVERY. STITCH.

Now every stitch can be yours — from pieced top to finished quilt. You've got fifteen inches of free-motion freedom at your fingertips and an unrivaled resolve to quilt to the finish line.

Getting started is easy. The Moxie Quick Start Guide is right here in the box and educational goodies like in-depth how-to videos, and a detailed, downloadable user manual are available at HandiQuilter.com/Moxie. Always up-to-date and available for your reference. Every Moxie comes with support from your local HQ retailer. HQ longarm quilting experts provide a wealth of quilting knowledge at HandiQuilter.com/video-library/.

Quilt without qualms, adventure with attitude - you've got Moxie.



Connect with us online and show us your Moxie! #quiltwithmoxie

## GET YOUR QUILT ON!

This accessory box has everything you need to get your new Moxie set up and ready to go:

- Moxie Quick Start Guide
- How-To Quilt Kit
- Moxie Decals
- BILT App Download Instructions
- Power Cord
- Machine Thread Mast
- Machine Spool Pin
- Bobbin Winder Thread Mast
- Bobbin Winder Spool Pin
- Needles Sizes 110/18 and 110/16
- 2.5mm, 3mm, and 4mm Hex Drivers
- 8mm/10mm Wrench
- EZ-Pen Oiler Bottle
- Lint Brush
- Bobbin Case Screwdriver
- Replacement O-Ring
- One Set Bobbin + Bobbin Case
- Four Additional Bobbins
- Open-Toe Hopping Foot



SEE ENCLOSED FOR APP DETAILS!

### LOADING YOUR QUILT (on the HQ Loft Frame)

The HQ Loft Frame offers two frame setup styles — "high position" and "low position". The frame user manual explains the difference between the two styles and details setup instructions for both. You can use the included "Quilt Top" and "Backing" decals to mark your poles for correct and consistent frame loading, depending on which setup you choose.



In both setup styles, the quilt top fabric should be facing right side up, quilt backing should be facing right side down.

